

Gigaset

S910 - S910 A

Congratulations

By purchasing a Gigaset, you have chosen a brand that is fully committed to sustainability. This product's packaging is eco-friendly!

To learn more, visit www.gigaset.com.



GIGASET. INSPIRING CONVERSATION.
MADE IN GERMANY


Gigaset S910/S910A – more than just a telephone

Your telephone sets new standards for the way you communicate at home.

The configuration and user interface of the cordless phone are excellent, providing you with first-class voice quality in handsfree mode, while Bluetooth™ offers you enormous flexibility.

The large TFT display, user-friendly keypad and clearly laid out menu are very simple to use.

Your phone can do a whole lot more:

- ◆ You can use Bluetooth™ for wireless communication with other devices (e.g. headsets) that also use this technology.
- ◆ You can synchronise your directories on your telephone, mobile phone and PC via Bluetooth™ using the Gigaset QuickSync software (→ page 69).
- ◆ You can save appointments (→ page 46) and anniversaries, e.g., birthdays (→ page 35), in your phone and it will remind you of them in advance.
- ◆ You can designate important people as VIPs to identify important calls from the ringtone (→ page 32).
- ◆ You can assign a picture to entries in the directory – in future the picture will appear every time you receive a call from this number (→ page 32).
- ◆ If you do not want to take calls where the caller has withheld their number, just set your handset to only ring if Calling Line Identification has not been withheld (→ page 60).
- ◆ If you do not wish to be disturbed, you can simply set up a time control so that your phone will only ring when it is convenient (→ page 60). VIP calls are still connected.
- ◆ You can assign important numbers to the number keys on your phone. The number is then dialled by simply pressing a key (→ page 56).
- ◆ Adapt your Gigaset to suit your handsfree requirements (→ page 59) and adjust the brightness of your keypad to suit you (→ page 58).
- ◆ View your personal pictures as a screensaver slide show (→ page 57).
- ◆ You can set the display to large font to increase readability in the directory (→ page 57).
- ◆ You can adapt the menu display to suit your individual requirements so that only the most important functions **Simplified (simplified mode)** or all functions **Complete (expert mode  icon.**
- ◆ Gigaset Green Home — Be environmentally aware when using your phone. Details about our ECO WDCT products can be found at www.gigaset.com/service.

You can find additional information about your phone at www.gigaset.com/gigasetS910.


Have fun using your new phone!

The handset at a glance



- 1 **Display** in idle status
- 2 **Battery charge status** (→ page 18)
- 3 **Side keys**
Set call (→ page 58) or ringtone volume (→ page 59)
- 4 **Display keys** (→ page 21)
- 5 **Message key** (→ page 36)
Access to call and message lists;
Flashes: new message or new call
- 6 **End call key, On/Off key**
End call, cancel function, go back one menu level (press briefly), back to idle status (press and hold), activate/deactivate handset (press and hold in idle status)
- 7 **IP Key** (→ page 55)
Insert IP number
- 8 **Hash key**
Keypad lock on/off (press and hold in idle status);
toggles between upper/lower case and digits
- 9 **Mute key** (→ page 31)
Mute the microphone
- 10 **Microphone**
- 11 **Recall key**
- Consultation call (flash)
- Insert a dialling pause (press and hold)
- 12 **Star key**
Ringtone on/off (press and hold);
with an open connection: switch between pulse dialling/tone dialling (press briefly);
text input: open table of special characters
- 13 **Headset socket** (→ page 18)
- 14 **Key 1**
Dial answer machine (S910A only)/network mailbox (press and hold)
- 15 **Talk key**
Flashes: incoming call;
Accept a call; open redial list (press briefly);
start dialling (press and hold)
- 16 **Handsfree key**
Switch between earpiece and handsfree mode
- 17 **Control key** (→ page 20)
- 18 **Signal strength** (→ page 18)
Green: Eco Mode (→ page 46) activated
- 19 **Answer machine symbol** (S910A only)
Answer machine switched on;
Flashes: answer machine is recording a message or is being operated by another internal party

The following symbols are displayed dependent on the settings and the operating status of your telephone:



Signalling

External call (→ page 29)



Alarm (→ page 48)



Internal call (→ page 50)



Anniversary (→ page 47)



Answer machine is recording (→ page 40)




Appointment (→ page 47)



The base at a glance

You can use the keys on the base to register handsets to the base, search for handsets (paging), (→ page 50) and operate the integrated answer machine (Gigaset S910A only).

Gigaset S910A base



1 Registration/Paging key

Press **briefly**: search for handsets (paging) (→ page 50).

Press and **hold**: register handsets and WDCT devices (→ page 49).

2 On/Off key

Activating/deactivating the answer machine.

3 Display

Lights up: answer machine is activated (0 is shown in the display).

00 flashes: the answer machine is recording a new message.

Flashes slowly: there are new messages. The number of **new** messages is displayed.

99 flashes quickly: the answer machine is full.

During message playback:

4 Play/Stop key

Play back new messages from answer machine or cancel playback (press **briefly**).

Play back new and old messages (press and **hold**).

5 Skip to next message (press once) or skip ahead two messages (press twice).

6 Skip back to the beginning of the message (press once) or skip back to the previous message (press twice).

7 Delete current message.

8 Adjust volume during message playback: = quieter; = louder.

While an external call is being signalled: adjust ringtone volume.

Please note:

If the answer machine is being operated from a handset or if it is recording a message (00 flashes), it cannot be operated from the base at the same time.

Gigaset S910 base



Registration/Paging key

– Press **briefly**: search for handsets (paging) → page 50.

– Press and **hold**: register handsets and WDCT devices (→ page 49).

Contents

Gigaset S910/S910A – more than just a telephone	1
The handset at a glance	2
The base at a glance	4
Safety precautions	8
First steps	9
Checking the package contents	9
Setting up the base and charger (if included)	10
Connecting the base	10
Connecting the charger (if included)	11
Setting up the handset for use	12
Changing the display language	15
Setting the date and time	16
Connecting the headset	18
What would you like to do next?	19
Using the phone	20
Control key	20
Display keys	21
Keys on the keypad	21
Side keys	21
Correcting incorrect entries	21
Using the menus	22
Activating/deactivating the handset	23
Activating/deactivating the keypad lock	23
Using this guide	24
Menu overview	26
Making calls	28
Making an external call	28
One Touch Call	28
Ending a call	28
Accepting a call	29
Calling Line Identification	29
Notes on calling line display (CLIP)	30
Handsfree mode	30
Switching to mute	31
Using the directory and lists	32
Directory	32
Redial list	35
Message key function	36
Answer machine list (Gigaset S910A only)	37
Calls list	37
List of missed alarms	38

Making cost-effective calls	39
Automatic network provider code (preselection)	39
Operating the Gigaset S910A base answer machine	40
Operating via the handset	40
Playing back messages	41
Activating/deactivating call screening	43
Setting the recording parameters	43
Resetting fast access for the answer machine using key 1	43
Operating when on the move (remote operation)	44
Using the network mailbox	45
Accepting a new message from the network mailbox	45
Playing back messages	45
ECO WDCT	46
Setting an appointment (calendar)	46
Displaying missed appointments, anniversaries	48
Setting the alarm clock	48
Using multiple handsets	49
Registering handsets	49
De-registering handsets	50
Locating a handset ("Paging")	50
Changing the base	50
Making internal calls	50
Listening in to an external call	51
Changing the name of a handset	51
Using a handset as a room monitor	52
Using Bluetooth devices	53
Handset settings	55
Quickly accessing IP number	55
Quick access to numbers and functions	56
Changing the display language	57
Setting the display	57
Setting keypad illumination	58
Activating/deactivating auto answer	58
Changing the speaker/earpiece volume	58
Setting a handsfree profile	59
Changing ringtones	59
Resource Directory	60
Activating/deactivating advisory tones	61
Setting your own area code	61
Restoring the handset default settings	62

Setting the base	62
Changing the Gigaset S910A base ringtones	62
Activating/deactivating music on hold	63
Protecting against unauthorised access	63
Resetting the base to the factory settings	63
Connecting the base to the PABX	64
Dialling mode and Flash	64
Setting pauses	64
Switching temporarily to tone dialling (DTMF)	64
Customer Care and Support	65
Questions and answers	65
Environment	66
Appendix	67
Caring for your telephone	67
Contact with liquid	67
Specifications	67
Writing and editing text	68
Additional functions via the PC interface	69
Accessories	70
Mounting the base on the wall (Gigaset S910 only)	72
Mounting the charger on the wall	72
Index	73

Safety precautions

Warning

Be sure to read this user guide and the safety precautions before using your telephone. Explain their content and the potential hazards associated with using the telephone to your children.



Use only the power adapter supplied, as indicated on the underside of the base.



Use only **rechargeable batteries** that correspond to the **specification provided on page 67**, as this could otherwise result in significant health risks and personal injury.



Using your telephone may affect nearby medical equipment. Be aware of the technical conditions in your particular environment e.g., doctor's surgery. If you use a medical device (e.g. a pacemaker), please contact the device manufacturer. They will be able to advise you regarding the susceptibility of the device to external sources of high-frequency energy. Please refer to the "Appendix" chapter for the specifications of this Gigaset product.



Do not hold the rear of the handset to your ear when it is ringing or when handsfree mode is activated. Otherwise you risk serious and permanent damage to your hearing.

Your Gigaset is compatible with the majority of digital hearing aids on the market. However, perfect function with all hearing aids cannot be guaranteed.

The handset may cause an unpleasant humming or whistling noise in hearing aids or cause them to overload. If you require assistance, please contact the hearing aid supplier.



Do not install the base or charger in bathrooms or shower rooms. The base and charger are not splashproof (→ page 67).



Do not use your phone in environments with a potential explosion hazard (e.g., paint shops).



If you give your Gigaset to a third party, make sure you also give them the user guide.



Remove faulty bases from use or have them repaired by our Service department, as they could interfere with other wireless services.

Please note

- ◆ Not all of the functions described in this user guide are available in all countries.
- ◆ The device cannot be used in the event of a power failure. It is also **not** possible to transmit **emergency calls**.


First steps

Checking the package contents



- 1 One Gigaset S910/S910A base
- 2 One power adapter
- 3 One Gigaset S910H handset
- 4 One phone cord
- 5 Two batteries
- 6 One battery cover
- 7 One belt clip
- 8 One plastic headset socket cover
- 9 One user guide

If you have purchased a **model with multiple handsets** the package should contain two batteries, a battery cover, a belt clip and a charger **9** with power adapter **10** for each additional handset.



Setting up the base and charger (if included)

The base and charger are designed for use in dry rooms in a temperature range of +5°C to +45°C.

- ▶ Set up the base at a central point in the building on a level, non-slip surface or mount the base (Gigaset S910 only) or charger on the wall (→ page 72).

Please note

Pay attention to the range of the base.

This is up to 300 m in unobstructed outdoor areas and up to 50 m inside buildings. The range is reduced when Eco Mode (→ page 46) is activated.


The phone's feet do not usually leave any marks on surfaces. However, due to the multitude of different varnishes and polishes used on today's furnishings, the occurrence of marks on the surfaces cannot be completely ruled out.

Please note:

- ◆ Never expose the telephone to the influence of heat sources, direct sunlight or other electrical devices.
- ◆ Protect your Gigaset from moisture, dust, corrosive liquids and fumes.

Connecting the base


- ▶ **First** connect the telephone jack **2** and insert the cables into the cable ducts.
- ▶ **Then** connect the power adapter **1**.



Please note:


- ◆ The power adapter must **always be connected**, as the phone will not operate without a mains connection.
- ◆ Use only the power adapter and phone cord **supplied**. Pin connections on telephone cables can vary (pin connections → page 68).

Connecting the charger (if included)



- ▶ Connect the flat plug from the power adapter **1**.
- ▶ Plug the power adapter into the plug socket **2**.

To disconnect the plug from the charger, press the release button **3** and disconnect the plug **4**.



Setting up the handset for use


The display and keypad are protected by plastic films.
Remove the protective films!

Inserting the batteries and closing the battery cover

Warning


Use only rechargeable batteries recommended by Gigaset Communications GmbH (→ page 67), i.e., Never use conventional (non-rechargeable) batteries, as this could result in significant health risks and personal injury. For example, the outer casing of the batteries could be damaged or the batteries could explode. The phone could also malfunction or be damaged as a result of using batteries that are not of the recommended type.

- ▶ Insert the batteries with the polarity in the correct direction. The polarity is indicated in/on the battery compartment.



- ▶ First insert the battery cover at the top.
- ▶ Then press the cover until it clicks into place.

To open the battery cover, for instance to replace the batteries, insert a coin into the cavity on the left-hand side of the casing, then pull the battery cover in an upward direction.




- ▶ Insert the plastic cover provided for the headset socket to ensure optimum sound in handsfree mode.



Attaching the belt clip

The handset has notches on each side to attach the belt clip.


- ▶ **To attach** — press the belt clip onto the back of the handset so that the protrusions on the belt clip engage with the notches.
- ▶ **To remove** — press the centre of the belt clip firmly with your right thumb, push the fingernail of your left index finger up between the clip and the housing and pull the clip in an upward direction.



Initial charging and discharging of the batteries

The correct charge status can only be displayed if the batteries are first fully charged **and** discharged.

- ▶ Charge the handset in the base for **8.5 hours**.



Please note

The handset must only be placed in the designated Gigaset S910/S910A base or charging cradle.


- ▶ After charging, remove the handset from the base and only replace it when the batteries are **fully discharged**.

Please note


- ◆ Each handset is registered with the base at the factory. You do not need to register the handset again. If you wish to use your handset with a different base or use further handsets with your base, you will need to register the handset manually (→ page 49).
- ◆ After the initial battery charge **and** discharge, you may place your handset in the base after every call.
- ◆ Always repeat the charging and discharging procedure if you remove the batteries from the handset and reinsert them.
- ◆ The batteries may warm up during charging. This is not dangerous.
- ◆ After a while, the charge capacity of the batteries will decrease for technical reasons.

Changing the display language


Change the display language if you do not understand the language currently set.




- ▶ Press right on the control key.



- ▶ **Slowly** press keys **9 WXYZ** and **5 JKL** one after the other.



The display for setting languages appears. The current language (e.g. English) is selected.




- ▶ Press down on the control key ...



... until the language you wish to use is marked, e.g., Espanol.

- ▶ Press the **right** key directly below the display to select this language.




The selection is marked with .

- ▶ Press and **hold** the end call key to return to idle status.

Setting the date and time

Set the date and time so that the correct date and time can be assigned to incoming calls, and so that the alarm can be used.




- ▶ Press the key below **Time** on the display screen to open the input field.
(If you have already set the time and date, open the input field via the menu → page 27.)




The **Date/Time** submenu is shown on the display.

- ▶ The active input position flashes. Enter day, month and year as an 8-digit number via the keypad, e.g.,

2 ABC 0 @ 1 @ 2 ABC 1 @ 0 @ 1 @ 4 GHI
for 2012/10/14.



Press the **right** or **left** control key to change the input position and correct an entry.




- ▶ Press **down** on the control key to switch to the time input field.

- ▶ Enter the hours and minutes in 4-digit format via the keypad, e.g.,
0 @ 7 PQRS 1 @ 5 JKL for 07:15 am.
Change the input position with the control key if necessary.






- ▶ Press the key below **Save** on the display screen to confirm your entry.








The display shows **Saved**. You will hear a confirmation tone and the handset will automatically return to idle status.

Display in idle status

Once the phone is registered and the time is set, the idle display is shown as in this example. If the answer machine is activated, the answer machine icon  is displayed in the header.










Displays


◆ Reception between the base and the handset:

- Poor to good:    
- No reception: 

Green: Eco Mode activated (→ page 46)

◆ Battery charge status:

-  white: charged over 66%
-  white: charged between 34% and 66%
-  white: charged between 11% and 33%
-  red: charged below 11%
-  flashes red: battery almost empty (less than 10 minutes talktime)
-     white: battery charging



Please note

If you have chosen a colour scheme with a white background, the white symbols are displayed in black.

◆ INT 1

Internal name of the handset (→ page 51)

Your answer machine is set with a pre-recorded announcement.

Your phone is now ready for use!

Connecting the headset



After removing the plastic cover, you can connect a headset to the left-hand side of your telephone with the 2.5 mm jack connector.

See the relevant product page at www.gigaset.com for information on recommended headsets.










The headset volume corresponds to the settings for the handset volume (→ page 58).

After using the headset, replace the plastic cover to enable optimum sound in handsfree mode.

What would you like to do next?

Now you have successfully set up your Gigaset, you will certainly want to adapt it to your personal requirements. Use the following guide to quickly locate the most important topics.



If you are unfamiliar with menu-driven devices such as other Gigaset telephones, read the section entitled "Using the phone" (→ page 20) first.

Information on is located here.
Setting the ringtone and volume	 page 59
Setting the earpiece volume	 page 58
Recording your own announcement for the answer machine	 page 40
Setting Eco Mode	 page 46
Operating the telephone on a PABX	 page 64
Registering existing Gigaset handsets to a base	 page 49
Transferring directory entries from existing Gigaset handsets to new handset(s)	 page 34
Using Bluetooth devices	 page 53
Connecting the phone to the PC	 page 69


If you have any questions about using your phone, please read the tips on troubleshooting (→ page 65) or contact our Customer Care team (→ page 65).

Using the phone





Control key

Below, the side of the control key that you must press in the respective operating situation is marked in black (top, bottom, right, left, centre), e.g.,  for "press right on the control key" or  for "press the centre of the control key".





The control key has a number of different functions:



When the handset is in idle status

-  Open the directory.
-  Open the main menu.
-  Open the list of handsets.
-  Call up the menu for setting the handset's call volume (→ page 58).







In the main menu

- , ,  or  Navigate to the required function.




In submenus and lists

-  /  Scroll up/down line by line.

In input fields

Use the control key to move the cursor up , down , right  or left . Press and **hold**  or  to move the cursor **word by word**.

During an external call

-  Open the directory.
-  Initiate an internal consultation call.
-  Adjust the loudspeaker volume for earpiece and handsfree mode.

Functions when pressing the middle of the control key

Depending on the operating situation, the key has different functions.


- ◆ **In idle status** the key opens the main menu.
- ◆ **In submenus, selection and input fields**, the key takes on the function of the display keys **OK**, **Yes**, **Save**, **Select** or **Change**.

Please note

These instructions demonstrate the main menu being opened by pressing the right of the control key and functions being actuated by pressing the appropriate display key. However, if you prefer, you can use the control key as described above.

Display keys





The functions of the display keys change depending on the particular operating situation. Example:





Some important display keys:

Options	Open a context-dependent menu.
OK	Confirm selection.
< C	Delete key: delete one character/word at a time from right to left.
Back	Go back one menu level or cancel operation.
Save	Store entry.
→→	Open the redial list.

Keys on the keypad

-  /  /  etc.
 Press the matching key on the handset.
- 
 Enter digits or letters.

Side keys

-  / 
 Press the keys on the right of the handset to set the volume for the **handset, ringtone, speaker, alarm**, signalling of **appointments** and the **headset** depending on the situation.


Correcting incorrect entries


You can correct incorrect characters in the input fields by navigating to the incorrect entry using the control key. You can then:

- ◆ Delete the **character** to the left of the cursor with the display key **< C** (**press and hold** to delete the **word**)
- ◆ Insert characters at the cursor position
- ◆ Overwrite the highlighted (flashing) character, e.g., when entering time and date.

Using the menus


Your telephone's functions are accessed using a menu that has a number of levels.

The menu display can be extended (**expert mode** ) or restricted (**simplified mode**). **Complete (expert mode)** mode is the active default setting.

Settings or functions that are only available in **Complete (expert mode)** are marked in these instructions by the .


Switching between simplified mode/complete mode and the menu overview (→ page 26).


Main menu (first menu level)


- ▶ When the handset is in idle status press the **right** control key  to open the main menu.

The main menu functions are shown in the display with icons. The icon for the selected function is highlighted in orange and the name of the associated function appears in the display header.

To access a function, i.e., to open the corresponding submenu (next menu level):

- ▶ Use the control key  to select the required function and press the display key **OK**.


Briefly press the display key **Back** or the end call key  to revert back to idle status.





Submenus

The functions in the submenus are displayed as lists (example on the right).

To access a function:


- ▶ Scroll to the function with the control key  and press **OK**.

Briefly press the display key **Back** or the end call key  to return to the previous menu level/cancel the operation.



Reverting to idle status

You can revert to idle status from anywhere in the menu as follows:

- ▶ Press and **hold** the end call key .

or:

- ▶ Do not press any key: after 2 minutes the display will **automatically** revert to idle status.

Settings that have not been saved by selecting the display keys **OK**, **Yes**, **Save** or **Change** are lost.

An example of the display in idle status is shown on page 18.

Activating/deactivating the handset



With the phone in idle status, press and **hold** the end call key (confirmation tone) to switch off the handset.
Press and **hold** the end call key again to switch the handset on.

Please note

When the handset is switched on, an animation showing the **Gigaset** logo is displayed for several seconds.

Activating/deactivating the keypad lock

The keypad lock prevents any inadvertent use of the phone.



Press and **hold** the hash key in idle status to activate or deactivate the keypad lock. You will hear the confirmation tone.

If the keypad lock is activated, you will see a message when you press a key.

The keypad lock deactivates automatically when you receive a call. It is reactivated when the call is finished.

Please note

When the keypad lock is active, you cannot even call emergency numbers.

Using this guide


The operating steps are shown in abbreviated form.


Example:

The illustration:


 →  → **Display + Keypad** → **Large Font** ( = on)

means:




- ▶ Press **right** on the control key  to open the main menu.



- ▶ Press right, left, down and up on control key  to navigate to the **Settings** submenu.


- ▶ Press the display key **OK** to confirm your selection.



- ▶ Press down on the control key  until the **Display + Keypad** menu option appears on the display.

- ▶ Press the display key **OK** to confirm your selection.



- ▶ Press down on the control key  until the **Large Font** menu option appears on the display.


- ▶ Press the display key **Change** to activate/deactivate the function.



The change is effective immediately and does not need to be confirmed.



- ▶ Press the key below **Back** on the display screen to jump back to the previous menu level.

or




Press and **hold** the end call key  to return to idle status.

Menu overview

Setting Simplified (simplified mode) or Complete (expert mode)

The menu display can be extended (**expert mode** ) or restricted (**simplified mode**). Menu options that are only available in **Complete** (expert mode) are marked with the  icon.

To change these settings:

Select  →  → **Menu View** → **Simplified** (simplified mode) or **Complete** (expert mode)
→ **Select** (the active mode is marked with )

Open the main menu: press  when the phone is in idle mode.

Bluetooth

Activation	→ page 53
Search for Headset	→ page 54
Search Data Device	→ page 54
Known Devices	→ page 54
Own Device	→ page 55

★ **Additional Features**

One Touch Call	→ page 28
Room Monitor	→ page 52



Resource Directory

Screensavers	→ page 61
Caller Pictures	→ page 61
Sounds	→ page 61
Capacity	→ page 61



Alarm Clock → page 48



Call Lists → page 37



Voice Mail

Play Messages	Network Mailbox	→ page 45
	Answ. Machine *	→ page 41
Answ. Machine *		→ page 40
Call Screening *		→ page 43
Announcements *	Rec. Announcement *	→ page 40
	Play Announcement *	→ page 40
	Del. Announcement *	→ page 40
Message Length *		→ page 43
Ring Delay *		→ page 43
Network Mailbox		→ page 45
Set Key 1 *	Network Mailbox	→ page 45
	Answ. Machine	→ page 41
Language *		→ page 43

* Base with answer machine only

**Organizer**

Calendar	→ page 46
Missed Alarms	→ page 48

**Directory**

→ page 32

**Settings**

Date/Time	→ page 16												
Audio Settings	<table> <tr> <td>Handset Volume</td> <td>→ page 58</td> </tr> <tr> <td>Handsfree Profiles</td> <td>→ page 59</td> </tr> <tr> <td> Advisory Tones</td> <td>→ page 61</td> </tr> <tr> <td>Ringtones(Handset)</td> <td>→ page 59</td> </tr> <tr> <td>Ringtones (Base)</td> <td>→ page 62</td> </tr> </table>	Handset Volume	→ page 58	Handsfree Profiles	→ page 59	Advisory Tones	→ page 61	Ringtones(Handset)	→ page 59	Ringtones (Base)	→ page 62		
Handset Volume	→ page 58												
Handsfree Profiles	→ page 59												
Advisory Tones	→ page 61												
Ringtones(Handset)	→ page 59												
Ringtones (Base)	→ page 62												
Display + Keypad	<table> <tr> <td>Screensaver</td> <td>→ page 57</td> </tr> <tr> <td>Large Font</td> <td>→ page 57</td> </tr> <tr> <td>Color Schemes</td> <td>→ page 57</td> </tr> <tr> <td> Display Backlight</td> <td>→ page 57</td> </tr> <tr> <td>Keypad Illumination</td> <td>→ page 57</td> </tr> </table>	Screensaver	→ page 57	Large Font	→ page 57	Color Schemes	→ page 57	Display Backlight	→ page 57	Keypad Illumination	→ page 57		
Screensaver	→ page 57												
Large Font	→ page 57												
Color Schemes	→ page 57												
Display Backlight	→ page 57												
Keypad Illumination	→ page 57												
Language	→ page 57												
Registration	<table> <tr> <td>Register Handset</td> <td>→ page 49</td> </tr> <tr> <td>De-reg. Handset</td> <td>→ page 50</td> </tr> <tr> <td>Select Base</td> <td>→ page 50</td> </tr> </table>	Register Handset	→ page 49	De-reg. Handset	→ page 50	Select Base	→ page 50						
Register Handset	→ page 49												
De-reg. Handset	→ page 50												
Select Base	→ page 50												
Telephony	<table> <tr> <td>Auto Answer</td> <td>→ page 58</td> </tr> <tr> <td>Area Codes</td> <td>→ page 61</td> </tr> <tr> <td>Listening In</td> <td>→ page 51</td> </tr> <tr> <td>Calls List Type</td> <td>→ page 37</td> </tr> <tr> <td>Preselection</td> <td>→ page 39</td> </tr> <tr> <td>Music on Hold</td> <td>→ page 63</td> </tr> </table>	Auto Answer	→ page 58	Area Codes	→ page 61	Listening In	→ page 51	Calls List Type	→ page 37	Preselection	→ page 39	Music on Hold	→ page 63
Auto Answer	→ page 58												
Area Codes	→ page 61												
Listening In	→ page 51												
Calls List Type	→ page 37												
Preselection	→ page 39												
Music on Hold	→ page 63												
System	<table> <tr> <td>Handset Reset</td> <td>→ page 62</td> </tr> <tr> <td>Base Reset</td> <td>→ page 63</td> </tr> <tr> <td>System PIN</td> <td>→ page 63</td> </tr> </table>	Handset Reset	→ page 62	Base Reset	→ page 63	System PIN	→ page 63						
Handset Reset	→ page 62												
Base Reset	→ page 63												
System PIN	→ page 63												
Menu View	<table> <tr> <td>Simplified</td> <td>→ page 26</td> </tr> <tr> <td>Complete</td> <td>→ page 26</td> </tr> </table>	Simplified	→ page 26	Complete	→ page 26								
Simplified	→ page 26												
Complete	→ page 26												
Eco Mode	→ page 46												

Making calls

If the backlight is deactivated (→ page 57) it is switched on by pressing any key. **Digit keys** appear on the display for pre-dialling; **all other keys** do not have any further functions.

Making an external call

External calls are calls using the public telephone network.




Enter the number and press the talk key.

or:



Press and **hold** the talk key and then enter the number.

You can cancel the dialling operation with the end call key .

You are shown the duration of the call while the call is in progress.

Please note

Dialling with the directory (→ page 33), call list (→ page 37), redial list (→ page 35) and automatic redial (→ page 36) saves you from repeatedly keying in phone numbers.

Continuing a call on a Bluetooth headset

Prerequisite: Bluetooth is activated; a connection has been established between the Bluetooth headset and the handset (→ page 53).

Press the talk key on the headset; it may take up to 5 seconds to establish a connection to the handset.

The menu to set the earpiece and microphone volume can be called up during a call by pressing the side keys.

For further details about your headset, see the accompanying user guide.

One Touch Call

You can set up your phone in such a way that pressing **any** key dials a previously stored number. This allows children, for example, who cannot enter a number, to call a certain number.

 → ★ → **One Touch Call**

► Change multiple line input:

Activation:


Select **On** to activate.


Call to:

Enter or change number.

► Press **Save** to save the settings.


When the function is activated, the idle display appears as shown below:



By pressing any key the saved number is dialled. Press the end call key , to cancel the dialling operation or to end the call.

Deactivating the One Touch Call

► **In idle status**, press the display key **Off**.


► Press and **hold** the hash key , to deactivate the One Touch Call.

Ending a call





Press the end call key.

Accepting a call

The handset indicates an incoming call in three ways: by ringing, by a display on the screen and by the flashing talk key .

Accept the call by:

- ▶ Pressing the talk key .
- ▶ Pressing the handsfree key .

Gigaset S910A: Instead of accepting the call, you can also redirect it to the answer machine:

Options → **Divert to AM** → **OK**

If the handset is in the base/charger and the **Auto Answer** function is activated (→ page 58), the handset automatically answers the call when you remove it from the base/charger.

If the ringer is intrusive, you can deactivate it:

Options → **Silence** → **OK**

You can accept the call as long as it is displayed on the screen.

Accepting a call on a Bluetooth headset

Prerequisite: Bluetooth is activated; a connection has been established between the Bluetooth headset and the handset (→ page 53).

Only press the talk key on the headset when the headset rings; it can take up to 5 seconds.

The menu to set the earpiece and microphone volume can be called up during a call by pressing the side keys.




For further details about your headset, see the accompanying user guide.


Calling Line Identification




When you receive a call, the caller's number is displayed on the screen if the following conditions are met:

- ◆ Your network provider supports CLIP, CLI.
 - CLI (Calling Line Identification): the caller's number is transmitted.
 - CLIP (Calling Line Identification Presentation): the caller's number is displayed.
- ◆ You have requested CLIP from your network provider.
- ◆ The caller has requested CLI from the network provider.

Call display with CLIP/CLI

If the caller's number is saved in your directory, the number is replaced by the corresponding directory entry ( /  /  symbol and name/number). If you have assigned a caller picture to that caller, this will also be displayed.



- 1 Ringtone icon
- 2  /  /  symbol from directory
- 3 Number or name of caller

The following is displayed in place of the number:

- ◆ **External**, if no number is transmitted.
- ◆ **Unavailable**, if the caller has not arranged Calling Line Identification.

Please note

The ringtone can be switched off for unknown calls (calls with Calling Line Identification withheld) (→ page 60).

Notes on calling line display (CLIP)

By default, the number of the caller is shown in the display of your Gigaset telephone. You do not have to make any other settings on your Gigaset telephone.

However, if the caller's number is not displayed, this can be due to the following:

- ◆ You have not ordered CLIP from your network provider or
- ◆ Your telephone is connected via a PABX or a router with an integrated PABX (gateway) that does not transmit all information.

Is your telephone connected via a PABX/gateway?

You can establish this by checking for an additional device connected between your telephone and house connection, e.g., a PABX, gateway etc. In most cases, simply resetting this device will remedy the situation:

- ▶ Briefly disconnect the mains plug of your PABX. Re-insert the plug and wait for the device to restart.

If the caller number is still not displayed:

- ▶ Check the CLIP settings of your PABX and activate this function if necessary. In the user guide for the device, search for the term "CLIP" (or an alternative term such as "calling line identification", "phone number transmission", "caller ID", ...). If necessary, contact the device manufacturer.

If this does not resolve the problem, it is possible that your network provider does not the CLIP service for this number.

Have you ordered the calling line display service from your network provider?

- ▶ Check whether your provider supports calling line display (CLIP) and that the function has been activated for you. If necessary, contact your provider.

Additional information on this subject can be found on the Gigaset homepage at: www.gigaset.com/service

Handsfree mode

In handsfree mode, instead of holding the handset to your ear you can put it down, for example on the table in front of you. This allows others to participate in the call.

Activating/deactivating handsfree mode

Activating while dialling



Enter the number and press the handsfree key.

- ▶ Inform your caller before you use the speaker function so that the caller knows a third party may be listening.


Switching between earpiece and handsfree mode



Press the handsfree key.

During a call and when listening to the answer machine (Gigaset S910A only), activate or deactivate handsfree mode.

If you wish to place the handset in the base/charger during a call:

- ▶ Press and hold the handsfree key  while placing the handset in the base/charger and for a further 2 seconds.

For instructions on adjusting the speaker volume (→ page 58).

Please note

If you have a headset connected, you can switch between the headset and handsfree mode.

Switching to mute

You can deactivate the microphone in your handset during an external call.



Press key to mute the handset.
The display shows **Microphone is off**.

Press the key again to reactivate the microphone.

Please note

A connected headset will also be muted.

Using the directory and lists

The options are:

- ◆ Directory
- ◆ Redial list
- ◆ Call lists
- ◆ List of missed appointments
- ◆ Answer machine list
(Gigaset S910A only).

You can create a personalised directory for your own handset. You can also send lists/entries to other handsets (→ page 34).

Directory

You can save up to 500 entries in the directory.


Please note

To quickly access a number from the directory (quick dial), you can assign the number to a key (→ page 56).

Directory

In the **directory**, you can save:

- ◆ Up to three numbers and associated first names and surnames
- ◆ E-mail addresses
- ◆ Anniversaries with reminder
- ◆ VIP ringtone with VIP icon
- ◆ Caller pictures.

You open the directory in idle status using the  key.

Length of the entries

3 numbers:
each max. 32 digits

First name and surname:
each max. 16 characters

E-mail address:
max. 64 characters

Saving a number in the directory

 → <New Entry>

► You can enter data in the following fields:

First Name: / Last Name:

Enter first names and/or surnames.

If you do not enter a name in either of the fields, the phone number is saved and displayed in place of a surname.




(For instructions on entering text and special characters, please see

→ page 68.)

Phone (Home): / Phone (Office): /

Phone (Mobile):

Enter a number in at least one of the fields.

When scrolling through the directory, the entries are highlighted by a prefixed symbol:  /  / .

E-Mail:

Enter the e-mail address.

Anniversary:

Select **On** or **Off**.

With setting **On**:

Enter **Anniversary Date** and **Anniv.**

(**Time**) and select reminder type: **Anniv.**

(**Signal**) → page 35.


Caller Picture:

If required, select a picture to be displayed when this person calls (see "Resource Directory", page 60).

Prerequisite: Calling Line Identification (CLIP).

Caller Melody (VIP):

Mark a directory entry as a **VIP** (Very Important Person) by assigning a specific ringtone to it. VIP calls are recognised by the ringtone.

When scrolling through the directory, VIP entries are highlighted by the  icon.

Prerequisite: Calling Line Identification (CLIP).

 **Save**

Press the display key.

Order of directory entries

Directory entries are generally sorted alphabetically by surname. Spaces and digits take first priority. If only the first name was entered in the directory, this is incorporated into the sort order instead of the surname.

The sort order is as follows:



1. Space
2. Digits (0–9)
3. Letters (alphabetical)
4. Other characters

To get round the alphabetical order of the entries, insert a space or a digit in front of the first letter of the surname. These entries will then move to the beginning of the directory.

Select a directory entry

 Open the directory.




You have the following options:

- ◆ Use  to scroll through the entries until the required name is selected.
- ◆ Enter the first letters of the name (max. 8), if necessary scroll to the entry with the  key.

The directory searches for the surname. If a surname has not been entered, the directory searches for the first name.

Select from the directory

 →  (Select entry)

 Press the talk key.
(If several numbers are entered, select the required number by pressing  and press the talk key  again).
The number is dialled.


Managing directory entries

Viewing entries


 →  (Select entry)

View Press the display key. The entry is displayed.

Options Press the display key.

The following functions can be selected with :

Display Number

To edit or add to a saved number, or to save it as a new entry, press  after the number is displayed.

Delete Entry



Delete selected entry.

Copy Entry

to Internal: Send a single entry to a handset (→ page 34).

vCard via Bluetooth: Send a single entry in vCard format via Bluetooth.



Editing entries

 →  (Select entry)


View **Edit** Press display keys one after the other.

- ▶ Carry out changes and save.



Using other functions

 →  (Select entry)

→ **Options** (Open menu)

The following functions can be selected with :

Display Number

Edit or add to a saved number and then dial with  or save as a new entry; to do so, press  after the number is displayed.

Edit Entry

Edit selected entry.

Delete Entry

Delete selected entry.

Copy Entry

to Internal: Send a single entry to a handset (→ page 34).

vCard via Bluetooth: Send a single entry in vCard format via Bluetooth.

Delete All

Delete all entries in the directory.

Copy All

to Internal: Send the complete list to a handset (→ page 34).

vCard via Bluetooth: Send the complete list in vCard format via Bluetooth.

Using the directory and lists

Available Memory

Display the number of entries that are still available in the directory (→ page 32).



Using quick dial keys


- ▶ Press and **hold** the required quick dial key (→ page 56).

Transferring the directory to another handset

Prerequisites:

- ◆ The sending and receiving handsets must both be registered to the same base.
- ◆ The other handset and the base can send and receive directory entries.

 →  (Select entry)
→ **Options** (Open menu) → **Copy Entry / Copy All** → **to Internal**

 Select the internal number of the receiving handset and press **OK**.

You can transfer several individual entries one after the other by responding to the **Entry copied - Copy next entry?** prompt with **Yes**.



A successful transfer is confirmed by a message and confirmation tone.

Please note:

- ◆ Entries with identical numbers are not overwritten on the receiving handset.
- ◆ The transfer is cancelled if the phone rings or if the memory of the receiving handset is full.
- ◆ Pictures and sounds assigned to entries are not transferred.

Transferring the directory as a vCard with Bluetooth

In Bluetooth mode (→ page 53), you can transfer directory entries in vCard format, e.g., to exchange entries with your mobile phone.

 →  (select entry)
→ **Options** (open menu)
→ **Copy Entry / Copy All**
→ **vCard via Bluetooth**


The list of "Known Devices" (→ page 54) is displayed.

 Select device and press **OK**.

Receiving a vCard with Bluetooth

If a device from the "Known Devices" list (→ page 54) sends a vCard to your handset, this occurs automatically. You are informed about it via the display.

If the sending device does not appear in the list, you will be asked on the display to enter the device PIN for the sending device:

 Enter the PIN for the **sending** Bluetooth device and press **OK**.

The transferred vCard is available as a directory entry.

Copying the displayed number to the directory

You can copy numbers displayed in a list, e.g., the call list or the redial list, to the directory.

A number is displayed:



Options → **Copy to Directory**


- ▶ Complete the entry (→ page 32).

Gigaset S910A: Message playback is interrupted during the number transfer from the answer machine list.

Copying a number or e-mail address from the directory

In some operating situations, you can open the directory to copy a number or e-mail address, for example. Your handset need not be in idle status.



- ▶ Depending on the operating situation, open the directory with  or .

 Select entry (→ page 33).


Storing an anniversary in the directory

For each number in the directory, you can save an anniversary and specify a time at which a reminder call should be made on the anniversary (default setting:

Anniversary: Off).

 →  (Select entry)

View **Edit** Press display keys one after the other.

 Scroll to the **Anniversary**: line.

 Select **On**.

► You can enter data in the following fields:

Anniversary Date

Enter day/month/year in 8-digit format.

Anniv. (Time)

Enter the hour/minute for the reminder call in 4-digit format.

Anniv. (Signal)

Select the reminder type.

Save Press the display key.


Please note


A time must be specified for reminder calls. If you select a visual signal, a time is not required and is automatically set to 00.00.

Deactivating anniversaries

 →  (Select entry)

View **Edit** Press display keys one after the other.


 Scroll to the **Anniversary**: line.

 Select **Off**.

Save Press the display key.



Reminder call on an anniversary

In idle status, a reminder call is indicated on the handset display and by the selected ringtone. The volume corresponds to the setting for internal calls (→ page 59).



You can:

Off Press the display key to acknowledge and end the reminder call.

During the reminder call, you can permanently change the volume by pressing the side keys  (louder) or  (quieter).


When you are on the phone, a reminder call is indicated on the handset with a **single** advisory tone.


Anniversaries that are indicated during a call and are not acknowledged are entered in the **Missed Alarms** list (→ page 38).


Redial list

The redial list contains the twenty numbers last dialled with the handset (max. 32 digits). If one of the numbers is in the directory, the corresponding name is displayed.

Manual redial


 Press the key **briefly**.

 Select entry.

 Press the talk key again. The number is dialled.


When a name is displayed, you can display the corresponding phone number by pressing the display key **View**.

Managing entries in the redial list

 Press the key **briefly**.

 Select entry.

Options Open menu.


The following functions can be selected with :

Copy to Directory

Copy an entry to the directory (page 32).

Automatic Redial

The selected number is automatically dialed at fixed intervals (at least every 20 seconds). The handsfree key flashes and "open listening" is activated.

- Party answers:
Press the talk key . The function is ended.
- Party does not answer:
The call is terminated after approx. 30 seconds. The function is ended after pressing any key or after ten unsuccessful attempts.

Display Number (as in the directory, page 33)

Delete Entry (as in the directory, page 33)

Delete All (as in the directory, page 33)

Message key function

Opening lists


Use the message key  to open the following list selection:


- ♦ Answer machine list (Gigaset S910A only) or network mailbox, if your network provider supports this function and fast access is set for the network mailbox (→ page 45).
- ♦ Calls List (→ page 37)
- ♦ List of missed alarms (→ page 38)


An advisory tone sounds as soon as a **new message** arrives in a list.

Depending in the type of the new entry, an icon appears in the display while in **idle status**:

Icon **New message...**

 ... in the answer machine list (Gigaset S910A only) or on the network mailbox

 ... in the missed calls list


 ... in the missed alarms list

The number of **new** entries is displayed under the corresponding icon.




Please note

If calls are saved in the network mailbox, you will receive a message if the appropriate settings have been made (see your network provider user guide).


If you have **new messages**, you see after pressing the message key  only lists containing **new messages**. If you do **not have new messages** you can see all lists containing messages. You always see the network mailbox list, if the number is entered (→ page 45).

The lists are displayed with the number of **new** messages:



Select a list with . To open, press **OK**.


Disable/enable flashing of the message key

You can select whether the message key  flashes (default setting) or does not flash when new messages arrive. Please do the following:

- ▶ Press the key sequence:



The following is displayed:



- ▶ Press one of the following keys to select the message type:




for missed calls



or for messages on the answering machine (Gigaset S910A only)/network mailbox

Your selection is displayed (e.g. 5 for missed calls); the current setting flashes:



- ▶ Press key or , to set the behavior for new messages:




message key flashes (it stops when the key is pressed)



message key does not flash

Your selection is displayed (e.g. 1):



- ▶ Press the display key **OK**.

Answer machine list (Gigaset S910A only)

You can use the **answer machine list** to listen to the messages that are on the answer machine.

Calls list

Prerequisite: Calling Line Identification (CLIP, page 29)

The calls list contains the last 30 numbers, depending on the type of list set:

- ◆ All calls
 - Accepted calls
 - Unanswered calls
 - Calls recorded by the answering machine (Gigaset S910 only)
- ◆ Missed calls
 - Unanswered calls and
 - Calls not recorded by the answering machine (Gigaset S910A only)

Setting the calls list type

→ → **Telephony** → **Calls List Type**

Missed Calls / All Calls

Select and press **OK**




(☒ = selected).




Press and hold (return to idle status).

The calls list entries are retained when you change the list type.

Open the calls list

When in idle status, open the list overview by pressing the message key  or via the menu  → .

Select the calls list with . The list is displayed with the number of **new** messages:


Calls List: (3)

OK Press the display key to open the list.

Example of list entries:

All Calls	
New Call	02
0123727859362922	
12.10.14	09:07
New Call	03
0123727859362922	
12.10.14	09:15
Back	Options

- ◆ List type (in header)
- ◆ Status and number of entry
 - **New Call:** new missed call.
 - **Old Call:** entry already read.
 - **Answ.:** call accepted.
 - **AM answ.:** Calls recorded by the answer machine (Gigaset S910A only)
- ◆ Number or name of caller
- ◆ Date and time of call (if set, page 16)

Press the talk key  to call the selected caller back.

Select the **Options** display key to select the following options:

Delete Entry

Delete selected entry.

Copy to Directory

Copy the number to the directory.

Delete All





Delete all entries.

When you quit the call lists, all entries are set to the status "old".

List of missed alarms

Missed (unacknowledged) appointments from the calendar (→ page 46) and anniversaries (→ page 35) are saved in the **Missed Alarms** list under the following circumstances:

- ◆ You do not accept an appointment/anniversary.
- ◆ The appointment/anniversary was signalled during a phone call.
- ◆ The handset is deactivated at the time of the appointment/anniversary.
- ◆ Automatic redial was activated at the time of an appointment/anniversary (→ page 36).

When in idle status, open the list overview by pressing the message key  or via the menu  → . Select **Missed Alarms:** with  and open the list by pressing **OK**.

Each entry is displayed with:

- ◆ Number or name
- ◆ Date and time

The most recent entry is at the head of the list.

Press the display key **Delete** to delete the selected entry.

If 10 entries are already stored in the list, the next appointment reminder will delete the oldest entry.

Making cost-effective calls

Make phone calls through a network provider who offers particularly low-cost call rates (call-by-call).

Automatic network provider code (preselection)

You can store a call-by-call number (preselection number), which is **automatically** placed in front of numbers when you dial them.

In the "**With Preselection**" list, specify the access codes or the first digits of the access codes that you wish to assign to the preselection number.

In the "**No Preselection**" list, enter the exceptions to the "**With Preselection**" list.



Example:

Preselection No.	0999
With Preselection	08
No Preselection	081 084

All numbers that start with 08, except for 081 and 084, are dialled with the preselection number 0999.

Phone number		Dialled number
07112345678	→	07112345678
08912345678	→	0999 08912345678
08412345678	→	08412345678

Saving preselection numbers

 →  → Telephony → Preselection
→ Preselection No.



Enter or change the preselection number (call-by-call number).



Save

Press the display key.

Save or change entries in the preselection lists

Each of the two lists can contain 20 entries, each with 6 digits.

Numbers may be prefixed according to the country in the "**With Preselection**" list. This means, for example, that all national calls or calls to the mobile network are **automatically** linked to the preselection number you have saved previously.

 →  → Telephony → Preselection
→ With Preselection / No Preselection



Select entry.




Enter or edit the first digits of the number.



Save

Press the display key.

Temporarily cancelling preselection

 (press and hold) → **Options**
→ Preselection off → (dial number)

Permanently deactivating preselection

 →  → Telephony → Preselection
→ Preselection No.

<C

Press and **hold** the display key until the preselection number is deleted.


Save

Press the display key.

Operating the Gigaset S910A base answer machine

You can access the answer machine via the handset, the buttons on the base (→ page 4) or by remote operation (from another phone/mobile phone). You can record your own announcement message or advisory message via the handset.


Operating via the handset

The handset loudspeaker activates **automatically** if you receive an acoustic prompt or message while operating. You can switch it off with the handsfree key .

Activating/deactivating and setting the answer machine mode



 →  → Voice Mail (✓ = on)

If the messages memory is full, you cannot activate the answer machine. You will receive an instruction to delete old messages.

When you switch the answer machine on, the remaining memory time is announced. If the time has not yet been set, an appropriate announcement is made (set time → page 16). The  icon appears in the display. The LED display on the base lights up (→ page 4).

The phone is supplied with a pre-recorded announcement. If a personal announcement has not been recorded, the pre-recorded announcement is used.

Recording a personal announcement

 →  → Announcements
→ Rec. Announcement
→ Press OK, talk after tone


OK Press the display key to start the recording.

You hear the ready tone (short tone).

- ▶ Now speak your announcement (at least 3 secs.).

Just as if making a call via the receiver, place the telephone against your ear and speak into the microphone at a normal volume.

OK Press the display key to end the recording.

Cancel recording with  or **Back**. Restart the recording with **OK**.

After recording, the announcement is played back for you to check. You can re-record the announcement with **OK**.

Please note:

- ◆ Recording ends automatically if the maximum recording time of 170 seconds is exceeded or there is a break in speech for more than 2 seconds.
- ◆ If you cancel the recording, the pre-recorded announcement is used again.

Playing back announcement

 →  → Announcements
→ Play Announcement

If you have not recorded a personal announcement, the pre-recorded announcement is played.

Deleting your personal announcement

 →  → Announcements
→ Del. Announcement

OK Press the display key to confirm the prompt.

Once you have deleted your announcement, the pre-recorded announcement is used again.

Please note

Deleting announcements can take some time.

Playing back messages

There are three ways to start playing back messages on the answering machine.


- ◆ Start message playback via the **Voice Mail** menu:

 →  → **Play Messages**

If you have entered a number for the network mailbox you still need to select the answering machine:

→ **Answ. Machine**


- ◆ Start message playback via the answering machine list:

 → **Ans. Machine:**

The list is displayed with the number of new messages:

Ans. Machine: (1)


OK Press the display key to open the list.

- ◆ Fast access to the answer machine:
To access the answer machine, simply **press and hold** the  key – you do not have to select it via the menu.
The integrated answering machine has already been preset at the factory. However, if you have set the network mailbox for fast access (→ page 45), you can change this setting.

 →  → **Set Key 1**

→ **Answ. Machine**

The setting for fast access applies to all registered handsets.

If you have new messages, playback will start with the first new message, otherwise with the first old message. The loudspeaker on the handset switches on **automatically**. To switch it off, press the handsfree key .

Messages consist of

- ◆ the message header (number/date/time) and
- ◆ the message body (recorded text).

The header is played back first, then the body.



The following is displayed (Example):



New 01
0123727859362922
12.10.14 09:07

Stopping and controlling playback



Controlling playback depends on the point in time at which the corresponding key is pressed.

During message playback:

 Pause playback. Press  again to resume.


or
 **During playback of message header:** Go to the start of the previous message.

During playback of message body: Go to the start of the current message.


or
 Go to the start of the next message.

 **During playback of message header:** Skip header.


During playback of message body: Go to the body of the next message.

Skipping back from the first message jumps to the last message. Skipping forward from the last message jumps to the first message.

If playback is interrupted for over a minute, the answering machine returns to idle status.

Additional functions during message playback

Options Press the display key. Playback stops.

Select the relevant function using :

Dial Number

Dial number.

Continue

Continue message playback.

Handset Volume

Setting Earpiece/Speaker volume.

Copy to Directory

Copy the caller's number to the directory.

Delete Old List

Delete **all old** messages.

Deleting an individual message

During playback:

Press the display key **Delete** .


Picking up a call from the answer machine

You can pick up a call while the answer machine is recording or is being operated via remote operation:

 / **Accept**

Press the talk or display key.

Recording stops and you can speak to the caller.

If two seconds of the call have already been recorded when you pick it up, the call is displayed as a new message. The  key on the handset flashes.

You can answer the call, even if it is not signalled on the handset.

Diverting an external call to the answer machine

You can divert an incoming external call to the answer machine, even if it is deactivated.

Prerequisite: Sufficient memory space is available on the answer machine.

An external call is signalled on the handset:

Options → **Divert to AM** → **OK**

The answer machine starts immediately in Answer & Record mode and records the call. The set time for ring delay (→ page 43) is ignored.

Activating/deactivating two-way record

You can record an **external** call with the answer machine.

- ▶ Inform the caller that the call is being recorded.

Options Open menu.

Two-way Record

Select and press **OK**.

Two-way record is indicated on the display by an advisory text and is added to the answer machine list as a new message.



End Press the display key to stop two-way record.

The maximum recording time depends on the memory available on the answer machine. If the memory is full, you will hear an end tone, the recording is aborted, and the call recorded up to that point is listed in the answer machine list as a new message.

Activating/deactivating call screening

While a message is recording, you can screen calls via the base loudspeaker and registered handsets.

Permanently activating/deactivating call screening

 →  → **Call Screening**
→ **Handset / Base** (☑ = on)

OK Select display key to activate/deactivate the function.

Call screening can be simultaneously activated on the base and handset.

Deactivating call screening for the current recording

You can deactivate the function for your own handset during the recording.

Silence Press the display key.


Setting the recording parameters

The answer machine has already been pre-set at the factory. Individual settings can be adjusted using the handset.

Setting the recording time

You can set the maximum recording time of a message: **1 Minute**, **2 Minutes**, **3 Minutes** oder **Unlimited**.


 →  → **Message Length**

 Select the recording time and press **OK** (☑ = selected).

Setting ring delay

You can set when you want the answering machine to accept a call: **Immediately**, **10 sec**, **18 sec**, **30 sec** oder **Auto**.

 →  → **Ring Delay**

 Select time and press **OK** (☑ = selected).

Information about ring delay


In **Auto** mode, the following applies for ring delay:

- ◆ If there are no new messages, the answer machine answers a call after 18 seconds.
- ◆ If there are new messages, the answer machine answers a call after 10 seconds.

When operating remotely (→ page 44), you can tell after approx. 15 seconds that there are no new messages (otherwise the answer machine would have already accepted your call). There are no call charges if you hang up now.


Changing the language for voice prompt and pre-recorded announcement

 →  → **Language**

The current language is indicated by a .

 Select language and press **Select**.


Resetting fast access for the answer machine using key 1

By default, key  has been assigned for fast access to the integrated answer machine. However, if you have set the network mailbox for fast access (→ page 45), you can reset this setting.

 →  → **Set Key 1**

Answ. Machine

Select and press **OK**.

Once you have selected the answer machine, press and **hold** key . You are connected directly.

The setting for fast access applies to all registered handsets.

Operating when on the move (remote operation)

You can check and activate your answer machine from any other telephone (hotel, pay phone etc.).

Prerequisites:

- ◆ You have set a system PIN other than 0000 (→ page 63).
- ◆ The phone you are using for remote operation has tone dialling (DTMF), i.e., you hear different tones when you press the keys. Alternatively, you can use a code transmitter (available from your mobile phone retailer).

Calling the answer machine and playing back messages



Dial your own number.

When you hear your announcement, press **9** and enter the system PIN.

You are informed whether any new messages have been recorded. The messages are now played back. You can now operate the answer machine with the keypad.

The following keys are used for operation:

- 1** To return to the start of the current message.
Press twice to go back to the previous message.
- 2** Pause playback. Press again to resume.
- 3** Go to the next message.
- 0** Delete current message.

Activating the answer machine

- Phone home and let the phone ring until you hear: "Please enter PIN".



Enter system PIN.

Your answer machine is activated. It tells you how much memory time is left.

The messages are now played back.

The answer machine cannot be deactivated remotely.

Using the network mailbox

The network mailbox is the answering machine in your provider's telephone network. More information is available from your provider.

You cannot use the network mailbox unless you have **requested** it from your provider.

Entering network mailbox number

In order to use the network mailbox quickly and easily via the network mailbox list and to use fast access, you will need to enter the number in your phone.

 →  → **Network Mailbox**



Enter the network mailbox number and press **Save**.

Accepting a new message from the network mailbox



When a message is recorded, you receive a call from the network mailbox. If you have requested Calling Line Identification, the display shows the network mailbox number. If you accept the call, the new messages are played back. If you do not accept the call, the network mailbox number is saved in the **calls list** (→ page 37).

Please note

Enter the network mailbox phone number into your directory along with the designation "Network Mailbox"; the display and the call list will then show this designation.

Playing back messages

There are three ways to call the network mailbox.

- ◆ Call the network mailbox via the **Voice Mail** menu:
 -  →  → **Play Messages**
→ **Network Mailbox**
- ◆ Access the network mailbox via the network mailbox list:


 → **Net Mailbox:**

The list is displayed with the number of **new messages**:

Net Mailbox: (0)

(0): The number of new messages is only displayed correctly if your network provider transmits this information.

OK Press the display key to call up the network mailbox.

- ◆ Fast access to the network mailbox: To access the network mailbox, simply **press and hold** the  key – you do not have to select it via the menu.

Gigaset S910: The network mailbox is preconfigured for fast access.

Gigaset S910A: The integrated answering machine is preconfigured for fast access. You can switch to the network mailbox.

 →  → **Set Key 1**
→ **Network Mailbox** ( = selected)

The setting for fast access applies to all handsets.

ECO WDCT

You are helping to protect the environment with your Gigaset S910/S910A.

Reducing energy consumption

By using a power-saving adapter plug, your telephone consumes less power.

Reducing radiation

The radiation from your telephone is reduced **automatically**:

- ◆ **Handset:** The closer the handset is to the base, the lower the radiation.
- ◆ **Base station:** The radiation is reduced to virtually zero when only one handset is registered and the handset is placed in the base.

You can reduce the radiation from the handset and base even more by using **Eco Mode**.


Eco Mode

Reduces the radiation of the base station and handset by 80% - whether you are making a call or not. **Eco Mode** reduces the range of the base station by approx. 50%. Using **Eco Mode** always makes sense when a reduced range is sufficient.




Switching off radiation

Activate/deactivate Eco Mode

 →  → **Eco Mode** → **Eco Mode**

Change Press the display key. (An advisory message appears when Eco Mode is **activated**; confirm with **OK**.)  = on.

Status displays

Display icon	
	Signal strength: – good to poor – no signal
 white	Eco Mode deactivated
 green	Eco Mode activated

Please note

Activating **Eco Mode** reduces the range of the base.


Setting an appointment (calendar)

You can use your handset to remind yourself of up to **30 appointments**. Anniversaries (→ page 35) entered in the directory are automatically recorded in the calendar.

Saving an appointment

Prerequisite: The date and time have already been set (→ page 16).

 →  → **Calendar**



- ◆ The current day is selected (highlighted in white).
- ◆ Days on which appointments have already been saved are highlighted in white.



Select the required day in the graphical calendar.

The selected day is highlighted in white. The current day is no longer highlighted.



Press the centre of the control key.

- ◆ If appointments have already been entered, this will open the list of saved appointments on that day. Select **<New Entry>** → **OK** to open the data input window.

- ◆ If no appointments have been entered, the data input window will open immediately to add the new appointment.
- ▶ You can enter data in the following fields:

Activation:

Select **On** or **Off**.

Date:

Enter day/month/year in 8-digit format.

Time:

Enter hours/minutes in 4-digit format.

Text:

Enter text (max. of 16 characters). The text appears as the appointment name in the list and is displayed on the screen during the appointment reminder. If you do not enter any text, only the date and time of the appointment are displayed.

Signal:


Select the reminder type.

Save

Press the display key.

Please note

If you have already saved thirty appointments, you will have to first delete an existing appointment before adding a new one.



You can either deactivate or answer an appointment reminder:

Off

Press the display key to deactivate the appointment reminder.

Please note

During a call, the appointment reminder is signalled by a short tone.

Managing appointments

→ → **Calendar**

Editing individual appointments



Select a day in the graphical calendar and press the control key . (Days on which appointments have already been saved are highlighted in white in the calendar).



Select appointment for the day.

You have the following options:

View

Press the display key and edit or confirm the entry.

or

Options

Open the menu for editing, deleting and activating/deactivating.

Deleting all appointments for one day

Options → **Delete all Appts.** → **OK**

Confirm the security prompt with **Yes**. All appointments are deleted.

Signalling appointments and anniversaries


An appointment reminder is signalled in idle status for 60 seconds with the selected ringtone at the volume that has been set for internal calls (→ page 59). **During the reminder call**, you can permanently change the volume by pressing the side keys (louder) or (quieter).


The name is displayed for anniversaries, while the entered text is displayed for appointments along with the time.

Displaying missed appointments, anniversaries

Missed appointments/anniversaries (→ page 35) are displayed in the **Missed Alarms** list if:

- ◆ You do not accept an appointment/anniversary.
- ◆ The appointment/anniversary was signalled during a phone call.
- ◆ The handset is deactivated at the time of the appointment/anniversary.
- ◆ Automatic redial was activated at the time of an appointment/anniversary (→ page 36).

The icon  and the number of **new** entries are shown in the display. The most recent entry is at the head of the list.

Open the list by pressing the **message key**  (→ page 36) or via the **menu**:

 →  → **Missed Alarms**

Select appointment/anniversary.

Information about the appointment/anniversary is displayed. A missed appointment is displayed with the appointment name and a missed anniversary is displayed with the last name and first name. The date and time will also be given.

Delete

Delete appointment.

If 10 entries are already stored in the list, the next appointment reminder will delete the oldest entry.

Setting the alarm clock

Prerequisite: The date and time have already been set (→ page 16).

Activating/deactivating and setting the alarm clock



► You can enter data in the following fields:

Activation:

Select **On** or **Off**.

Time:

Enter the wake-up time in 4-digit format.

Occurrence:

Select **Daily** or **Monday-Friday**.

Volume:

Set the volume (1–6).

Melody:



Select melody.

Save

Press the display key.

In idle status, the  icon and wake-up time are displayed.

A wake-up call is signalled on the display and with the selected ringtone (→ page 2). The wake-up call sounds for 60 seconds. If no key is pressed, the wake-up call is repeated twice at five minute intervals and then switched off for 24 hours.

While the wake-up call sounds, you can permanently change the volume by pressing the side keys  (louder) or  (quieter).

During a call, the wake-up call is only signalled by a short tone.

Deactivating the wake-up call/ repeating after a pause (snooze mode)

Prerequisite: A wake-up call is sounding.

Off Press the display key. The wake-up call is deactivated.

or

Snooze Press the display key or any key. The wake-up call is deactivated and then repeated after 5 minutes. After the second repetition the wake-up call is deactivated for 24 hours.

Using multiple handsets

Registering handsets

You can register up to six handsets to your base.

A Gigaset S910H handset can be registered on up to four bases.

Manually registering a Gigaset S910H to a Gigaset S910/ S910A

You must activate manual registration of the handset on both the handset (1) and the base (2).

When the registration process has completed successfully, the handset returns to idle status. The handset's internal number is

shown in the display e.g., INT 1. If not, repeat the procedure.

1) On the handset


The handset is not registered to a base.


Register Press the display key.

The handset is already registered to a base:

 →  → **Registration**
→ **Register Handset**

If the handset is already registered to four bases:

 Select base, e.g., **Base 3** and press **OK**.

 If required, enter the system PIN for the base and press **OK**.

A message appears stating that the handset is searching for a base that is ready for registration.

2) On the base

Within 60 seconds press and **hold** the registration/paging key on the base (→ page 4) (approx. 3 seconds).

Registering other handsets

You can register other Gigaset handsets and handsets for other devices with GAP functionality as follows. .

1) On the handset


Start to register the handset as described in its user guide.


2) On the base


Press and **hold** the registration/paging key on the base (→ page 4) (approx. 3 sec.).

De-registering handsets

You can de-register any other registered handset from any registered Gigaset S910H handset.

 →  → **Registration**
→ **De-reg. Handset**

 Select the internal subscriber you wish to de-register and press **OK**.
(The handset you are currently using is highlighted with <).

 Enter the current system PIN and press **Save**.


Yes Press the display key.

Locating a handset ("Paging")

You can locate your handset using the base.

- ▶ **Briefly** press the registration/paging key on the base (→ page 4).
- ▶ All handsets will ring simultaneously ("paging"), even if the ringtones are deactivated.


Ending paging

- ▶ **Briefly** press the registration/paging key on the base or press the talk key  on the handset.

Changing the base

If your handset is registered to more than one base, you can set it to a particular base.

 →  → **Registration** → **Select Base**


 Select one of the registered bases and press **Select**.

Making internal calls

Internal calls to other handsets registered on the same base are free.

Calling a specific handset

 Initiate internal call.

 Enter the number of the handset.

or:

 Initiate internal call.

 Select handset.


 Press the talk key.

Calling all handsets ("group call")

 Press and **hold**.

or:

 Initiate internal call.


 Press the star key.
or

Call All Select

 Press the talk key.


All handsets are called.


Ending a call

 Press the end call key.

Transferring a call to another handset/making an internal consultation call

You are talking to an external participant and can call an internal participant at the same time to forward the call or to consult.

 Open the list of handsets.
The external participant hears music on hold, if activated (→ page 63).

 Select a handset or **Call All** and press **OK**.

When the internal participant answers:

- ▶ If necessary, announce the external call.

Either

Press the end call key. The external call is transferred to the other handset.

Or**Back**

Press the display key. You are reconnected with the external participant.

When transferring a call, you can also press the end call key before the internal participant answers.

Then, if the internal participant does not answer or the line is busy, the call will automatically return to you.

Accepting call waiting

If you receive an **external** call during an **internal** call, you will hear the call waiting tone (short tone). With Calling Line Identification, the caller's number will appear in the display.



Press the end call key to end the internal call.



Press the talk key to accept the external call.

Listening in to an external call

Prerequisite: The **Listening In** function must be activated.

You are conducting an external call. An internal participant can listen in on this call and take part in the conversation. All the participants are made aware of additional listeners by a signal tone.

 Activating/deactivating listening in

→ → **Telephony** → **Listening In**

Press **Change** to activate/deactivate the function (= on).

Internal listening in

The line is engaged with an external call. Your screen will display information to that effect. To listen in to the external call.



Press and **hold** the talk key.

You can listen in to the call. All participants hear a signal tone. During this time, this handset displays the **Conference** message and it is not possible to dial another number from this handset.

Ending listening in

Press the end call key.

All participants hear a signal tone.

If the **first** internal participant presses the end call key , the handset that has "listened in" remains connected to the external participant.

Changing the name of a handset

The names "INT 1", "INT 2" etc. are assigned automatically on registration. You can change these names. The name must be no more than 10 characters. The changed name is displayed in every handset's list.



Open the list of handsets. Your own handset is indicated by .



Select handset.

Options

Open menu.

Rename

Enter name.



Press the display key.

Using a handset as a room monitor

If the room monitor is activated, a previously saved destination number is called as soon as a set noise level is reached. You can save an internal or external number in your handset as the destination number. All of the handset keys are deactivated, with the exception of the display keys.

The room monitor call to an external number is terminated after approximately 90 seconds. The room monitor call to an internal number (handset) is terminated after approximately 3 minutes (depending on the base). When the room monitor is activated, all keys are locked except the end call key. The handset's speaker is muted.

When the room monitor is activated, incoming calls to the handset are indicated **without a ringtone** and are only shown on the screen. The display and keypad are not illuminated and advisory tones are also turned off.

If you accept an incoming call, the room monitor is suspended for the duration of the call, but the function **remains** activated.

If you deactivate then reactivate the handset, the room monitor remains activated.

Warning!

- ◆ Always check the operation of the room monitor before use. For example, test its sensitivity. Check the connection if you are diverting the room monitor to an external number.
- ◆ When the function is switched on, the handset's operating time is considerably reduced. If necessary, place the handset in the base/charger. This ensures that the battery does not run down.
- ◆ Ideally the handset should be positioned 1 to 2 metres away from the baby. The microphone must be directed towards the baby.
- ◆ The connection to which the room monitor is diverted must not be blocked by an activated .

Activating the room monitor and entering the destination number

 → ★ → Room Monitor


- You can enter data in the following fields:


Activation:

Select **On** to activate.

Alarm to:

Select **Internal** or **External**.


External number: Select the number from the directory (press display key ) or enter it manually.

Internal number: Select display key  → . Select handset or **Call All** to call all registered handsets → **OK**.


In idle status, the destination number or the internal destination number .

Sensitivity:

Select noise level sensitivity (**Low** or **High**).

- Press  to save the settings.

When the room monitor function is activated, the idle display appears as shown below:



Changing the set destination number

→ ★ → Room Monitor

- Enter and save number as described in "Activating the room monitor and entering the destination number" (→ page 52).

Cancel/deactivate room monitor

Press the end call key to cancel the call when the **room monitor is activated**.

In idle status, press the display key to deactivate room monitor mode.

Using Bluetooth devices

Your Gigaset handset can communicate wirelessly via Bluetooth™ with other devices using this technology.

Before you can use your Bluetooth device, activate Bluetooth, ensure the devices are visible and then register the handset.

You can register one Bluetooth headset to the handset. You can also register up to five data devices (PCs, PDAs and mobile phones) to send and receive directory entries as vCards or exchange data with the computer (→ page 69).

To use the phone numbers, dialling codes (country and area code) must be stored in the directory (→ page 61).

You will find a description of how to operate your Bluetooth devices in the user guides for these devices.

Please note

- ◆ You can operate headsets on your handset that have the **headset** or **handsfree profile**. If both profiles are available, the handsfree profile is used to communicate.
- ◆ It can take up to five seconds to establish a connection between your handset and a Bluetooth headset. This applies both when a call is accepted using the headset or transferred to the headset, and when a number is dialled from the headset.

Activating/deactivating Bluetooth mode

→ → Activation

Press to activate or deactivate Bluetooth mode (= activated).

In idle status, the icon on the handset shows that Bluetooth mode is activated (→ page 2).

Registering Bluetooth devices

The distance between the handset in Bluetooth mode and the activated Bluetooth device (headset or data device) should be no more than 10 m.

Please note

- ◆ If you register a headset, any headset that is already registered will be over-written.
- ◆ If you would like to use a headset with your handset that is already registered to another device (e.g., to a mobile phone), please **deactivate** this connection before you start the registration process.

→ → Search for Headset / Search Data Device

The search can take up to 30 seconds.

Once the device has been found, its name is shown on the display.

Options Press the display key.

Trust Device

Select and press **OK**.



Enter the PIN for the Bluetooth device **you want to register** and press **OK**.

The device is saved in the list of known devices.

Cancelling/repeating current search

To cancel search:

Cancel Press the display key.

Repeat search if necessary:

Options Press the display key.

Repeat Search



Select and press **OK**.


Editing the list of known (trusted) devices

Open list

 →  → Known Devices

A corresponding icon appears next to each device name in the list displayed:

Icon	Meaning
	Bluetooth headset
	Bluetooth data device

If a device is connected, the corresponding icon is shown in the header of the display instead of .

Viewing entries

Open list →  (select entry)

View Press the display key.

Device name and address are displayed.

Go back with **OK**.

De-registering Bluetooth devices

Open list →  (select entry)

Options Press the display key.

Delete Entry

Select and press **OK**.

Please note

If you deregister an activated Bluetooth device, it may try to reconnect as an "unregistered device".

Changing the name of a Bluetooth device

Open list →  (select entry)

Options Press the display key.

Edit Name Select and press **OK**.



Change the name.

Save Press the display key.

Rejecting/accepting an unregistered Bluetooth device

If a Bluetooth device that is not registered in the list of known devices tries to connect with the handset, you will be prompted on the display to enter the PIN for the Bluetooth device (bonding).

◆ Reject



Briefly press the end call key.

◆ Accept



Enter the PIN for the Bluetooth device **you want to accept** and press **OK**.

If you have accepted the device, you can use it temporarily (i.e., as long as it is within receiving range or until you deactivate the handset) or save it to the list of known devices.

Once the device's PIN has been confirmed

- Save to the list of known devices: press display key **Yes**.
- Use temporarily: press display key **No**.

Changing the Bluetooth name of the handset

You can change the handset name used to identify it on the display of another Bluetooth device.



→ → **Own Device**



Press the display key



Change the name.



Press the display key

Handset settings

Your handset is preconfigured, but you can change the settings to suit your individual requirements.

Quickly accessing IP number

You can assign an **IP number** from the directory to the **digit key** .

The number is then inserted in the dial preparation screen by simply pressing the key .

Assigning digit key

Prerequisite: You have not yet assigned a number to the digit key .

- ▶ Press and **hold** the digit key or
Press the digit key **briefly** and press the display key **QuickDial**.

The Directory opens.

- ▶ Select an entry and press **OK**.

The entry is saved to the digit key .

Please note


If you delete or edit the entry in the Directory at a later date, this will not affect the assignment to the digit key.

Changing an assignment


When the handset is in idle status:


- ▶ **Briefly** press the digit key , then press the display key **Change** to change the assignment or to delete the assignment.

Selecting number

Prerequisite: The digit key  already has a number assigned to it.

When the handset is in idle status:

- ▶ Press and **hold** the digit key .

or
Briefly press the digit key , then press the display key with the number/name (abbreviated if necessary).



Dial preparation is started with the stored number.

When the dial preparation screen is active with some dial numbers:

- ▶ Press and **hold** the digit key.

The stored number is inserted at the beginning of the already typed numbers.

Quick access to numbers and functions

You can assign a **number from the directory** to each of the **digit keys**  to .

The left and right **display keys** have a default **function**. You can change the assignment (→ page 56).


The number is then dialled or the function started by simply pressing a key.

Assigning digit keys

Prerequisite: You have not yet assigned a number to the digit key.

- ▶ Press and **hold** the digit key

or

Press the digit key **briefly** and press the display key .

The directory opens.

- ▶ Select an entry and press .

The entry is saved to the corresponding digit key.

Please note

If you delete or edit the entry in the directory at a later date, this will not affect the assignment to the number key.


Selecting numbers/changing an assignment

Prerequisite: The digit key already has a number assigned to it.

When the handset is in idle status

- ▶ Press and **hold** the digit key:
The number is dialled immediately.

or

- ▶ **Briefly** press the digit key.
Press the display key with the number/name (abbreviated if necessary) to select the number or
press the display key  to change the assignment or to delete the assignment.

The number is dialled immediately.

When the dial preparation screen is active with some dial numbers:

- ▶ Press and **hold** the digit key.

The stored number is inserted at the current cursor position.

Changing display key assignments

- ▶ Press and **hold** the left or right side of the display key.

The list of possible key assignments is opened. The following can be selected:

INT

Internal calls (→ page 50).

Alarm Clock

Assign menu for setting and activating the alarm clock to a key (→ page 48).

Calendar

Display graphical calendar (→ page 46).

Bluetooth

Assign the Bluetooth menu to a key (→ page 53).



Redial


Display the redial list.

- ▶ Select an entry and press .

Changing the display language

You can view the display texts in different languages.

 →  → **Language**

The current language is indicated by a .


 Select language and press **Select**.

Setting the display

Setting the screensaver/slide show

When in idle status, a picture or a slide show (all the pictures are displayed one after the other) from the **Screensaver** folder of the **Resource Directory** (→ page 60) or the time can be displayed as a screensaver. This will replace the idle status display.

The screensaver is not displayed in certain situations, e.g., during a call or if the handset is de-registered.

If a screensaver is activated, the **Screensaver** menu option is marked with .

 →  → **Display + Keypad**
→ **Screensaver**

The current setting is displayed.


► You can enter data in the following fields:


Activation:


Select **On** (screensaver is displayed) or **Off** (no screensaver).


Selection:

Select screensaver or

 Press the display key. The active screensaver is displayed.

 Select screensaver and press **OK**.

 Press the display key.

Briefly press the end call key  to return to the idle display.



Please note

If the **analogue clock** has been set as the screensaver, the **second hand** is shown only when the handset is in the base.

Setting large font

You can increase the font size of print and symbols in the directory to improve readability. Only one entry is shown at a time on the display instead of several entries and names are abbreviated if necessary.

 →  → **Display + Keypad**
→ **Large Font**

 Press display key ( = on).

Setting the colour scheme

You can set the display to be shown in various colour combinations.

 →  → **Display + Keypad**
→ **Color Schemes**

Select **Color Scheme** (1 to 5) and press **OK**.

Setting the display backlight

Depending on whether or not the handset is in the base/charger, you can activate or deactivate the backlight. If it is activated, the display is permanently dimmed. If the backlight is deactivated it is switched on by pressing any key. **Digit keys** appear on the display for pre-dialling; **all other keys** do not have any further functions.

 →  → **Display + Keypad**
→ **Display Backlight**

The current setting is displayed.

Handset settings

- ▶ You can enter data in the following fields:

In Charger

Select **On** or **Off**.

Out of Charger

Select **On** or **Off**.

Please note

With the **On** setting, the standby time of the handset can be significantly reduced.

Save

Press the display key.

Setting keypad illumination

The brightness of the keypad illumination can be set to one of five levels.

 →  → **Display + Keypad**
→ **Keypad Illumination**

The current setting is displayed.

- ▶ Modify the entry:


Brightness:

Select 1 (darkest) to 5 (brightest).

Save


Press the display key.

Activating/deactivating auto answer

If you activate this function, when you receive a call you can simply lift the handset out of the base/charger without having to press the talk key .

 →  → **Telephony** → **Auto Answer**

Change

Press display key ( = on).



Changing the speaker/earpiece volume

You can set the loudspeaker volume for handsfree mode and the earpiece volume to five different levels.

During a conversation via the earpiece or in handsfree mode:




Press the side key to call up the **Handset Volume** menu.


Change the volume by pressing  (louder) or  (quieter).

or



Press the control key to call up the **Handset Volume** menu. Set the earpiece or speaker volume by pressing .

The setting will automatically be saved after approximately 3 seconds, if not then press the display key **Save**.

If  is assigned to another function:

Options

Open menu.

Volume

Select and press **OK**.

Configure setting (see above).

Please note

- ◆ The settings for the earpiece also apply to a connected headset.
- ◆ You can also set the call volume using the menu (→ page 27).

Setting a handsfree profile

You can set different handsfree profiles to optimally adapt your phone to your environment.

Profile 1

The optimum setting for most connections and set as default.

Profile 2

Optimum volume in handsfree mode. However, this means that the participants cannot speak at the same time as the person speaking is given preferential transmission (making two-way conversations difficult).

Profile 3

Optimises two-way conversations, both callers can hear each other, even if they talk at the same time.


Profile 4

Optimised for special connections. If the default setting (profile 1) does not provide optimum sound, please give this a try.

In idle status:



 →  → **Audio Settings**
→ **Handsfree Profiles**

 Select handsfree profile (1 to 4).

 Press the display key to save the setting.

Changing ringtones

◆ Volume:

You can choose between five volumes (1–5; e.g., volume 3 = ) and the "crescendo" ringtone (6; volume increases with each ring = ).

◆ Ringtones:

You can select a ringtone from a list of pre-loaded melodies.



You can select various ringtones, melodies or any sound from the Resource Directory (→ page 60).


You can set different ringtones for the following functions:

- ◆ Internal Calls
- ◆ External Calls


Setting volume/melodies


In idle status:



 →  → **Audio Settings**
→ **Ringtones(Handset)**
→ **Volume/Melodies**

 Setting volume/melodies for internal calls.

 Scroll to the next line.

 Setting volumes/melodies for external calls.

 Press the display key to save the setting.

While the phone is ringing, you can permanently change the volume by pressing the side keys  (louder) or  (quieter).



Additionally for external calls:

You can specify a time period when you do not want the telephone to ring, e.g., during the night.

 →  → **Audio Settings**
→ **Ringtones(Handset)** → **Time Control**

Handset settings

For External Calls:

Select **On** or **Off**.

If the time control is activated:

Suspend ring from:

Enter the start of the period in 4-digit format.

Suspend ring until:

Enter the end of the period in 4-digit format.



Please note


During this period, you will continue to receive calls from numbers to which you have assigned a personalised melody in the directory (VIP).

Activating/deactivating the ringtone for unknown calls.

You can set your handset so that it doesn't ring for calls where Calling Line Identification has been withheld (not answering machine). The call will only be signalled on the display.

In idle status:

 →  → **Audio Settings**
→ **Ringtones(Handset)**
→ **Anon. Calls Silent**

Press **Change** to activate or deactivate the function ( = on).

Activating/deactivating the ringtone


You can deactivate the ringtone on your handset before you answer a call or when the handset is in idle status; the ringtone can be deactivated permanently or just for the current call. The ringtone cannot be re-activated while an external call is in progress.

Deactivating the ringtone permanently

 Press and **hold** the star key.

The  icon appears in the display.

Reactivating the ringtone


 Press and **hold** the star key.


Deactivating the ringtone for the current call

Silence Press the display key.

Activating/deactivating the alert tone

In place of the ringtone, you can activate an alert tone. When you receive a call, you will hear a **short tone** ("Beep") instead of the ringtone.

 Press and **hold** the star key and **within 3 seconds**:

Beep Press the display key. A call will now be signalled by **one** short alert tone.
 appears in the display.

Resource Directory



The resource directory on the handset manages sounds, which you can use as ringtones, and pictures, which you can use as caller pictures or as screensavers. Prerequisite: Calling Line Identification (CLIP). The resource directory can manage the following media types:

Type	Format
Sound	
Ringtones	Internal
Monophonic	Internal
Polyphonic	Internal
Imported sounds	WMA, MP3, WAV
Picture	BMP, JPG, GIF
– Caller picture	128 x 86 pixels
– Screensaver	128 x 160 pixels


Various mono and polyphonic sounds and pictures are preconfigured on your handset. You can listen to the available sounds and view the pictures.

You can download pictures and sounds from a PC (→ page 69). If there is not enough memory available, you must first delete one or more pictures or sounds.

Playing back sounds/viewing caller pictures


 →  → **Screensavers / Caller Pictures / Sounds** (select entry)

Pictures:

View Press the display key. The selected picture is displayed. Switch between pictures using the  key.

If you have saved a picture in an invalid file format, you will see an error message after selecting the entry.


Sounds:

The selected sound is played back immediately. Switch between the sounds using the  key.

You can set the volume during playback.

Options Open menu.

Volume Select and press **OK**.


 Set volume.

Save Press the display key.

Deleting/renaming a picture/sound

You have selected an entry.

Options Open menu.

If a picture/sound cannot be deleted () , these options are not available. You can select the following functions:

Delete Entry

The selected entry is deleted.

Rename

Change the name (max. 16 characters) and press **Save**. The entry is stored with the new name.

Checking the memory

You can check how much memory is available for screensavers and caller pictures.



 →  → **Capacity**

Activating/deactivating advisory tones

Your handset uses advisory tones to tell you about different activities and statuses. The following advisory tones can be activated/deactivated independently of each other:

- ◆ **Key tone:** every key press is confirmed.
- ◆ **Acknowledge tones:**
 - **Confirmation tone** (ascending tone sequence): at the end of an entry/setting and when a new entry arrives in the answer machine list or call list
 - **Error tone** (descending tone sequence): when you make an incorrect entry
 - **Menu end tone:** when scrolling to the end of a menu
- ◆ **Battery low beep:** the battery needs charging.

In idle status:

 →  → **Audio Settings**
→ **Advisory Tones**

► You can enter data in the following fields:

Key Tones:

Select **On** or **Off**.

Confirmation:

Select **On** or **Off**.

Battery:

Select **On** or **Off**.

Save Press the display key.

Setting your own area code

To transfer phone numbers (e.g., in vCards), it is essential that your area code (international and local area code) is saved on the phone.

Some of these numbers are already preset.


 →  → **Telephony** → **Area Codes**


Check that the (pre)set area code is correct.


Setting the base


► You can enter data in the following fields:

 Select/change input field.



 Navigate in the input field.

 If necessary, delete number:
press the display key.

 Enter number.

 Press the display key.

Example:

Area Codes	
International code:	
00 - 86	
Local access code:	
0 - []	
 	


Restoring the handset default settings

You can reset individual settings and changes that you have made.

The following settings are **not** affected by a reset:

- ◆ Registration to the base
- ◆ Date and time
- ◆ Entries in the calendar
- ◆ Entries in the directory, the call lists and the content of the resource directory

 →  → **System** → **Handset Reset**



 Press the display key.

Setting the base

The base settings are carried out using a registered Gigaset S910H handset.

Changing the Gigaset S910A base ringtones

◆ Volume:

You can choose between 5 volumes (1–5; e.g., volume 2 = ) and the "crescendo" ringtone (volume increases with each ring = ). Select volume 0 to deactivate the base ringer.



◆ Ringtones:

You can select a ringtone from a list of pre-loaded melodies.

◆ Time control:


You can specify a time period when you do not want the telephone to signal external calls e.g., during the night.

In idle status:

 →  → **Audio Settings**
→ **Ringtones (Base)**

Use  to select the following:



Volume

Set volume by using .

Melodies

Set the ringer melody by using .

Time Control

Activation is switched on or off by pressing  ( = activated)

Settings

Ringer off from: / **Ringer off until:**


Enter time in 4-digit format.

Please note

During this period, you will continue to receive calls from numbers to which you have assigned a personalised melody in the directory (VIP).

Activating/deactivating music on hold

 →  → **Telephony** → **Music on Hold**

Press **Change** to activate or deactivate the music on hold ( = on).

Protecting against unauthorised access

Protect the system settings of the base with a PIN known only to yourself. The system PIN must be entered when, for example, registering/de-registering a handset to/from the base or when restoring the default settings.

Changing the system PIN

You can change the 4-digit system PIN set on the base (default setting: **0000**) to a 4-digit PIN known only by you.

Gigaset S910A: Setting a system PIN facilitates remote operation of the answer machine (→ page 44).

 →  → **System** → **System PIN**



Enter the current system PIN and press **OK**.



Enter your new system PIN and press **OK**.

Resetting the system PIN

If you have forgotten your system PIN, you can reset the base to the original code **0000**:

Disconnect the power cable from the base. Hold down the registration/paging key on the base while reconnecting the power cable to the base. Hold down the key for at least 5 seconds.

The base has now been reset and the system PIN set to **0000**.

Please note

All handsets are de-registered and must be re-registered. All settings are reset to the factory settings.

Resetting the base to the factory settings

When the settings are restored:

- ◆ Date and time are retained
- ◆ Handsets are still registered
- ◆ **Eco Mode** is activated
- ◆ The system PIN is not reset.

 →  → **System** → **Base Reset**



Enter the system PIN and press **OK**.

Yes

Press the display key.

Connecting the base to the PABX


The following settings are only necessary if your PABX requires them; see the PABX user guide.

Dialling mode and Flash

Changing the dialling mode

The following dialling modes can be selected:

- ◆ Tone dialling (DTMF)
- ◆ Pulse dialling (PD).

 → * Δ # ↵ 0 @ 5 JKL # ↵ 1 ∞ 1 ∞
→ 1 ∞ OK Pulse dialling mode (DP).

Or:

→ 0 @ OK Tone dialling (DTMF).

Please note

Tone dialling (DTMF) is now the most common dialling mode. Pulse dialling mode (PD) is only used for a few old PABXs.

Setting recall

Your phone is preset for operation on the main connection. For operation on a PABX, you may have to change this value. Please refer to the user guide for your PABX.

 → * Δ # ↵ 0 @ 5 JKL # ↵ 1 ∞ 2 ABC




Enter digits for the recall time and press **OK**.

0 = 80 ms; 1 = 100 ms; 2 = 120 ms;
3 = 400 ms; 4 = 250 ms; 5 = 300 ms;
6 = 600 ms; 7 = 800 ms

Setting pauses

Changing the pause after line seizure

You can change the length of the pause that is inserted between pressing the talk key  and sending the number.

 → * Δ # ↵ 0 @ 5 JKL # ↵ 1 ∞ 9 WXYZ



Enter number for the length of the pause (1 = 1 sec.; 2 = 3 secs.; 3 = 7 secs.) and press **OK**.

Changing the pause after recall key

You can change the length of the pause if your PABX requires this (refer to the user guide for your PABX).

 → * Δ # ↵ 0 @ 5 JKL # ↵ 1 ∞ 4 GHI



Enter a digit for the length of the pause (1 = 800 ms; 2 = 1600 ms; 3 = 3200 ms) and press **OK**.

Switching temporarily to tone dialling (DTMF)

If your PABX still operates with pulse dialling (PD), but you need tone dialling for a connection (e.g., to listen to the network mailbox), you must switch to tone dialling for the call.

Prerequisite: You are conducting a call or have already dialled an external number.

 Press the star key.

After the call ends, pulse dialling is automatically reactivated.

Customer Care and Support

Hotline: 4006 706 007

Questions and answers


If you have any questions about the use of your phone, you can contact us 24/7 at www.gigaset.com/service.

The table below contains a list of common problems and possible solutions.

Registration or connection problems with a Bluetooth headset.


- › Reset the Bluetooth headset (see the user guide for your headset).
- › Delete registration data from the handset when deregistering the device (→ page 54).
- › Repeat the registration process (→ page 54).

The display is blank.

1. The handset is not switched on.
 - › Press and **hold** the end call key .
2. The battery is empty.
 - › Charge the battery or replace it (→ page 12).

Not all menu items are displayed.

The menu display is restricted (**simplified mode**).

- › Activate extended menu display **Complete** (**expert mode**  (→ page 26).

"No Base" flashes on the display.

1. The handset is outside the range of the base.
 - › Move the handset closer to the base.
2. The base's range is reduced because Eco Mode is activated.
 - › Deactivate Eco Mode (→ page 46) or reduce the distance between the handset and the base.
3. The base is not switched on.
 - › Check the base power adapter (→ page 10).

"Please register handset" or "Place handset on base" flashes on the display.

Handset has not been registered with the base or has been deregistered.

- › Register the handset (→ page 49).

Handset does not ring.

1. The ringtone is deactivated.
 - › Activate the ringtone (→ page 60).
2. The phone only rings if the phone number has been transferred.
 - › Switch on the ringtone for unknown calls (→ page 60).

You cannot hear a ringtone/dialling tone from the fixed line network.

The phone cord supplied has not been used or has been replaced by a new cord with the wrong pin connections.

- › Please always use the phone cord supplied or ensure that the pin connections are correct when purchasing from a retailer (→ page 10).

Error tone sounds after system PIN prompt.


You have entered the wrong system PIN.

- › Reset the system PIN to 0000 (→ page 63).

Forgotten the system PIN.

- › Reset the system PIN to 0000 (→ page 63).

The other party cannot hear you.

You have pressed the mute button . The handset is "muted".

- › Reactivate the microphone (→ page 31).

The number of the caller is not displayed despite CLIP.

Calling Line Identification is not enabled.

- › **The caller** should ask the network provider to enable Calling Line Identification (CLI).

You hear an error tone when keying an input (a descending tone sequence).

Action has failed/invalid input.

- › Repeat the operation.
Watch the display and refer to the user guide if necessary.

You cannot listen to messages on the network mailbox.

Your PABX is set for pulse dialling.

- › Set your PABX to tone dialling.

Gigaset S910A only:

No time is specified for a message in the call list.

Date and time have not been set.

- › Set the date and time (→ page 16).

The answer machine announces "PIN is incorrect" during remote operation.

1. You have entered the wrong system PIN.
 - › Enter the system PIN again.
2. The system PIN is still set to 0000.
 - › Set the system PIN to something other than 0000 (→ page 63).

The answering machine is not recording any messages or a personal announcement.

Its memory is full.

- › Delete old messages.
- › Play back new messages and delete.

Exclusion of liability

Some displays may contain pixels (picture elements), which remain activated or deactivated. As a pixel is made up of three sub-pixels (red, green, blue), it is possible that pixel colours may vary.

This is completely normal and does not indicate an error.

Environment

Our environmental mission statement

We, Gigaset Communications GmbH, bear social responsibility and are actively committed to a better world. Our ideas, technologies and actions serve people, society and the environment. The aim of our global activity is to secure sustainable life resources for humanity. We are committed to a responsibility for our products that comprises their entire life cycle. The environmental impact of products, including their manufacture, procurement, distribution, use, service and disposal, are already evaluated during product and process design.

Further information on environmentally friendly products and processes is available on the Internet at www.gigaset.com.

Environmental management system



Gigaset Communications GmbH is certified pursuant to the international standards EN 14001 and ISO 9001.

ISO 14001 (Environment): certified since September 2007 by TüV SÜD Management Service GmbH.

ISO 9001 (Quality): certified since 17/02/1994 by TüV SÜD Management Service GmbH.

Ecological energy consumption

The use of ECO WDCT (→ page 46) saves energy and makes an active contribution towards protecting the environment.

Disposal

Batteries should not be disposed of in general household waste. Observe the local waste disposal regulations, details of which can be obtained from your local authority.

All electrical and electronic equipment must be disposed of separately from general household waste using the sites designated by local authorities.



If a product displays this symbol of a crossed-out rubbish bin, the product is subject to European Directive 2002/96/EC.

The appropriate disposal and separate collection of used equipment serve to prevent potential harm to the environment and to health. They are a prerequisite for the re-use and recycling of used electrical and electronic equipment.

For further information on disposing of your used equipment, please contact your local authority or your refuse collection service.

Appendix

Caring for your telephone

- ▶ Wipe the device with a **damp cloth** or an **antistatic cloth**. Do not use solvent or a microfibre cloth.
- ▶ Impairments in the high-gloss finish can be carefully removed using display polishes for mobile phones.

Never use a dry cloth as this can cause static.

Contact with liquid

If the device comes into contact with liquid:

1. **Unplug the power supply and/or remove the battery from the handset immediately.**
2. Allow the liquid to drain from the device.
3. Pat all parts dry. Place the device (handset with the battery compartment open and the keypad facing down) in a dry, warm place **for at least 72 hours (not in a microwave, oven etc.)**.
4. **Do not switch on the device again until it is completely dry.**

When it has fully dried out, you will normally be able to use it again.

Specifications

Batteries

Technology:

Nickel-metal-hydride (NiMH)

Size: AAA (Micro, HR03)

Voltage: 1.2 V

Capacity: 550 - 1000 mAh

The device is supplied with two approved batteries.

Handset operating times/charging times

This Gigaset can charge batteries up to a capacity of 1000 mAh. The use of special high-performance batteries or batteries with high capacities is not recommended for cordless phones.

The operating time of your Gigaset depends on the capacity and age of the batteries and the way they are used. (All times are maximum possible times).

	Capacity (mAh) approx.			
	550	700	800	1000
Standby time (hours)*	140/50	165/58	185/67	230/83
Talktime (hours)	11	12	14	17
Operating time for 1.5 hrs of calls per day (hours)**	85	95	110	135
Charging time in base (hours)	7.5	8.5	10	12
Charging time in charger (hours)	6.5	7.5	8.5	10.5

* without/with display backlight

** without display backlight

(Setting the display backlight → page 57)

Due to the constant progression in battery development, the list of recommended batteries in the FAQ section of the Gigaset Customer Care pages is regularly updated:

www.gigaset.com/service

Base power consumption

	S910	S910A
In standby mode	approx. 0.7 W * < 0.4 W **	approx. 0.7 W * < 0.4 W **
During a call	approx. 0.5 W	approx. 0.5 W

* Charged handset in base

** Handset not in base

General specifications


WDCT

WDCT standard	Is supported
No. of channels	80 duplex channels
Radio frequency range	2402 MHz - 2483,5 MHz
Duplex method	Time multiplex, 10 ms frame length
Pulse repetition rate	100 Hz
Pulse transmission length	840 µs
Channel grid	864 kHz
Bit rate	576 kbit/s
Modulation	GFSK
Language code	32 kbit/s
Transmission power	25 mW average power per channel, 250 mW pulse power
Range	Up to 300 m outdoors, up to 50 m indoors
Base power supply	220 V ~/50 Hz
Environmental conditions in operation	+5°C to +45°C, 20% to 75% relative humidity
Dialling mode	DTMF (tone dialling)/ PD (pulse dialling)

Bluetooth

Radio frequency range	2402–2480 MHz
Transmission power	4 mW pulse power

Pin connections on the telephone jack



Writing and editing text

The following rules apply when writing text:

- ◆ Each key between **[0 @]** and **[9 wxyz]** is assigned several letters and characters.
- ◆ Control the cursor with **[←]**, **[→]**, **[↑]**, **[↓]**. Press and **hold** **[←]** or **[→]** to move the cursor **word by word**.
- ◆ Characters are inserted at the cursor position.
- ◆ Press the star key **[* Δ]** to display the table of special characters. Select the required character and press the display key **[Insert]** to insert the character at the cursor position.
- ◆ Press and **hold** **[0 @]** to **[9 wxyz]** to enter digits.
- ◆ Press display key **[< C]** to delete the **character** to the left of the cursor. Press and **hold** to delete the **word** to the left of the cursor.
- ◆ The first letter of the name of directory entries is automatically capitalised, followed by lower case letters.

Setting upper/lower case or digits

Repeatedly press the hash key **[# ↔]** to change the text input mode.

123	Writing digits
Abc	Upper case *
abc	Lower case

* First letter in capitals, all others in lower case

The active mode is indicated at the bottom right of the screen.

Writing names

- ▶ Enter the individual letters/characters by pressing the corresponding key.

The characters assigned to the key are shown in a selection line at the bottom left of the screen. The selected character is highlighted.

- ▶ **Briefly** press the key several times in succession to select the required letter/character.

Standard characters

	1x	2x	3x	4x	5x	6x	7x	8x	9x	10x
1 00	1									
2 ABC	a	b	c	2	ä	á	à	â	ã	ç
3 DEF	d	e	f	3	ë	é	è	ê		
4 GHI	g	h	i	4	ï	í	ì	î		
5 JKL	j	k	l	5						
6 MNO	m	n	o	6	ö	ñ	ó	ò	ô	õ
7 PQRS	p	q	r	7	ß					
8 TUV	t	u	v	8	ü	ú	ù	û		
9 WXYZ	w	x	y	9	ÿ	ý	æ	ø	å	
0 @	¹⁾	.	,	?	!	²⁾	0			

1) Space

2) Line break

Additional functions via the PC interface

To enable your handset to communicate with the PC, the "**Gigaset QuickSync**" program must be installed on your PC (free to download at www.gigaset.com/gigaset910).

After installing "**Gigaset QuickSync**", connect the handset to your computer using Bluetooth (→ page 53).

Your computer must be equipped with a suitable dongle.

Transferring data

Start the "**Gigaset QuickSync**" program. You can now:

- ◆ Synchronise your handset directory with Outlook
- ◆ Download caller pictures (.bmp) from the computer to the handset,
- ◆ Download pictures (.bmp) as a screen-saver from the computer to the handset.
- ◆ Download sounds (ringtones) from the computer to the handset.

During the transfer of data between handset and PC, you will see **Data transfer in progress** on the display. During this time the keypad is disabled, and incoming calls will be ignored.

Accessories

Gigaset handsets

Upgrade your Gigaset to a cordless PABX:

Gigaset S910H handset

- ◆ Brilliant sound quality in handsfree mode
- ◆ High-quality keypad with illumination
- ◆ Plus/minus key for simple volume control
- ◆ 1.8" TFT colour display
- ◆ Bluetooth®
- ◆ Directory for up to 500 vCards
- ◆ Talk/standby time of up to 13h/180h, standard batteries
- ◆ Large font for directory
- ◆ Brilliant sound quality in handsfree mode:
4 handsfree settings
- ◆ Caller pictures, screensaver (analogue and digital clock)
- ◆ Download ringtones
- ◆ ECO WDCT
- ◆ Alarm clock
- ◆ Calendar with appointment scheduler
- ◆ Night mode with time-controlled ringtone deactivation
- ◆ No interruptions from unknown calls
- ◆ One Touch Call mode

www.gigaset.com/gigasetS910h



Gigaset E710H handset

- ◆ Hear whom the call is for with VIP ringtones
- ◆ High-quality keypad
- ◆ 1.8" b/w display
- ◆ Directory for 150 entries
- ◆ Talk/standby time of up to 18 h/260 h,
standard batteries
- ◆ Brilliant sound quality in handsfree mode
- ◆ Screensaver (digital clock)
- ◆ ECO WDCT
- ◆ Alarm clock
- ◆ Night mode with time-controlled ringer deactivation
- ◆ No interruptions from anonymous calls

www.gigaset.com/gigasetE710h



Gigaset C510H handset

- ◆ High-quality keypad
- ◆ 1.6" b/w display
- ◆ Directory for up to 80 entries
- ◆ Talk/standby time of up to 19 h/255 h, standard batteries
- ◆ Brilliant sound quality in handsfree mode
- ◆ Screensaver
- ◆ ECO WDCT
- ◆ Alarm clock
- ◆ Night mode with time-controlled ringer deactivation
- ◆ No interruptions from anonymous calls

www.gigaset.com/gigasetc510h



Compatibility



For more information on handset functions in relation to Gigaset bases, please visit:
www.gigaset.com/compatibility

All accessories and batteries are available from your phone retailer.





Use only original accessories. This will avoid possible health risks and personal injury, and also ensure that all the relevant regulations are complied with.

Mounting the base on the wall (Gigaset S910 only)



Mounting the charger on the wall



Index

A

- Access protection 63
- Accessories 70
- Acknowledge tones 61
- Activating
 - advisory tones 61
 - answer machine 40
 - answer machine
 - (remote operation)..... 44
 - appointment 46
 - handset 23
 - keypad lock 23
 - listening in 51
 - room monitor 52
 - two-way record 42
- Advisory tones 61
- Alarm clock 48
- Alert tone 60
- Anniversary 35
 - deactivating 35
 - missed 38, 48
 - saving in the directory..... 35
- Announcement (answer machine)..... 40
- Answer machine 40
 - activating/deactivating..... 40
 - recording a personal
 - announcement/advisory
 - message 40
 - remote operation 44
- Answer machine list 36, 37
- Appointment 46
- Appointment/anniversary
 - display missed 48
- Appointments
 - activating/deactivating..... 47
 - deleting..... 47
 - managing 47
- Approval 66
- Area code
 - setting own area code 61
- Assigning a number key 55, 56
- Auto answer 58
- Automatic
 - network provider preselection 39
 - redial 36
 - ring delay 29, 58

B

- Base
 - changing..... 50
 - connecting 10
 - connecting to PABX 64
 - restoring to factory settings..... 63
 - setting ringtone 62
 - setting up 10
 - settings 62
 - system PIN 63
- Battery
 - charging 2, 3
 - display 2, 3
 - icon..... 2, 3
 - inserting 12
 - tone 61
- Birthday, see Anniversary
- Bluetooth
 - accepting a call 29
 - activate 53
 - changing device name 54, 55
 - de-registering devices..... 54
 - list of known devices 54
 - registering devices 54
 - transferring directory (vCard) 34

C

- Calendar 46
- Call
 - accepting 29
 - accepting (Bluetooth) 29
 - connect participant 51
 - ending 28
 - external 28
 - internal 50
 - picking up from answer machine..... 42
 - transferring (connecting) 50, 51
 - two-way record 42
- Call duration..... 28
- Call lists 37
- Call screening during recording 43
- Call waiting
 - internal call..... 51
- Call-by-call 39
- Caller Picture 32, 60
- Calling
 - external 28
 - internal 50
- Calling line display, notes 30

Index

Calling Line Identification	29
Cancelling	
preselection	39
Caring for your telephone	67
Changing	
destination number (room monitor) ..	53
device name (Bluetooth)	54, 55
dialling mode	64
display language	15, 57
earpiece volume	58
name of a handset	51
pauses	64
ringtone	59, 62
speaker volume	58
system PIN	63
Character set	69
Charge status display	2, 3
CLI, CLIP	29
Colour scheme	57
Complete mode (expert mode)	26
Confirmation tone	61
Connecting base to PABX	64
Connecting the headset	18
Control key	2, 20
Correcting incorrect entries	21
D	
Deactivating	
advisory tones	61
answer machine	40
appointment	46
handset	23
keypad lock	23
listening in	51
two-way record	42
Delete key	21
Deleting	
announcement for answer	
machine	40
characters	21
De-registering (handset)	50
De-registering devices (Bluetooth)	54
Destination number (room monitor)	52
Dialling	
dialling mode	64
using Quick Dial	55
using quick dial	34, 56
using the directory	33

Directory	32
copying number from text	34
managing entries	33
opening	20
order of entries	33
saving anniversary	35
saving entry	32
sending entry/list to handset	34
transferring a vCard (Bluetooth)	34
using to enter numbers	34
Display	
backlight	57
changing display language	15, 57
colour scheme	57
directory memory	34
in idle status	18, 22
memory (resource directory)	61
missed anniversaries	38
missed	
appointments/anniversaries	48
network mailbox message	45
number (CLI/CLIP)	29
screensaver	57
setting	57
Display keys	2, 21
assigning	55, 56
Disposal	66

E

Earpiece volume	58
Eco mode	46
ECO WDCT	46
E-mail address	
copying from the directory	34
End call key	2, 28
Ending, call	28
Entry	
saving, changing (preselection)	39
selecting from directory	33
Environment	66
Error tone	61
Expert mode	26, 65
External call	
forwarding to ans. mach.	42

F

- Fast access
 - answer machine 41, 43
 - network mailbox 45
- Flashing of the message key
 - disable/enable 37

G

- General troubleshooting 65
- Group call 50

H

- Handset
 - activating/deactivating 23
 - advisory tones 61
 - changing name 51
 - colour scheme 57
 - contact with liquid 67
 - de-registering 49, 50
 - display backlight 57
 - display language 15, 57
 - earpiece volume 58
 - idle status 22
 - keypad illumination 58
 - large font 57
 - list 20
 - locating 50
 - muting 31
 - paging 50
 - registering 49
 - registering to a different base 50
 - restoring to factory settings 62
 - screensaver 57
 - set up for use 12
 - setting 55
 - speaker volume 58
 - transferring a call 50
 - using multiple 49
 - using room monitor 52
- Handset mode 30
- Handset operating time
 - in room monitor mode 52
- Handsfree key 2
- Handsfree mode 30
- Handsfree profile 59
- Hash key 2, 23
- Headset (Bluetooth) 53
- Headset socket 18
- Hearing aids 8
- Help 65

I

- Icon
 - alarm clock 48
 - for new messages 36
 - keypad lock 23
 - ringtone 60
- Idle status (display) 18, 22
- Idle status, returning to 22
- Illumination
 - keypad 58
- Incorrect entries (correction) 21
- Installing, base 10
- Internal
 - listening in 51
 - making calls 50
- Internal call 50
- call waiting 51
- IP number 55

K

- Key
 - assigning to a function or number 55, 56
- Key 1 (fast access) 2, 43
- Keypad illumination 58
- Keypad lock 23
- Keys
 - control key 2, 20
 - delete key 21
 - display keys 2, 21
 - end call key 2, 28
 - fast access 2, 43
 - fast access to answer machine 41
 - fast access to network mailbox 45
 - handsfree key 2
 - hash key 2, 23
 - message key 2
 - mute key 2
 - on/off key 2
 - quick dial 34
 - recall key 2
 - side keys 2
 - star key 2
 - talk key 2, 28

L

- Language, display 15
- Large font 57

Index

List

- answer machine 36, 37
- call lists 37
- handsets 20
- known devices (Bluetooth)..... 54
- missed calls..... 37
- network mailbox..... 36
- Listening in to a call 51
- Locating, handset 50
- Lock
 - activating/deactivating keypad lock .. 23

M

Making calls

- accepting a call 29
- external 28
- internal 50
- Making cost-effective calls 39
- Manual redial 35
- Medical equipment 8
- Memory
 - directory 34
 - resource directory..... 61

Menu

- end tone 61
- opening..... 20
- overview 26
- using 22

Menu display

- complete (expert mode) 65
- expert mode..... 26, 65
- simplified mode 65

Message

- playing back..... 41, 45

Message key

- disable/enable flashing..... 37
- opening lists..... 36

Messages

- key 2

Microphone 2

Missed

- anniversary..... 48
- appointment 48
- Missed calls..... 37
- Music on hold..... 63
- Mute key 2
- Muting the handset 31

N

Name

- of a handset 51
- Network mailbox..... 45
- Network provider preselection,
 - automatic..... 39
- Night mode see Time Control
- Number
 - as destination for room monitor..... 52
 - copying from directory 34
 - copying to the directory..... 34
 - displaying caller's number (CLIP) 29
 - entering with directory 34
 - saving in directory 32

O

- On/Off key..... 2
- One Touch Call..... 28
- Operating remotely 44
- Order in directory 33

P

PABX

- connecting base 64
- pauses 64
- setting dialling mode..... 64
- setting recall..... 64
- switching to tone dialling..... 64

Package contents 9

Paging 50

Pause

- after line seizure 64
- after recall key 64

PC interface 69

PD (pulse dialling)..... 64

Picture

- Caller 32, 60
- deleting..... 61
- renaming..... 61

PIN change

- system PIN 63

Pin connections..... 68

Playing back

- announcement (answer machine) 40
- message (answering machine) 41, 45

Power adapter 8

Power consumption..... 67

Preselection 39

- cancelling 39

Protecting the phone against access 63
Pulse dialling 64

Q

Questions and answers 65
Quick Dial 55
Quick dial. 32, 56

R

Range 10
Recall 64
Recall key. 2, 64
Recording
 recording time (ans. mach.) 43
 two-way record 42
Redial 35
Registering (handset) 49
Registering devices (Bluetooth) 54
Reminder call 35
Resource directory 60
Ring delay 43
Ringer
 setting melody. 62
Ringtone
 changing 59, 62
 setting volume. 59, 62
Ringtone deactivated for unknown call . 60
Room monitor 52

S

Screensaver. 57
Search directory 33
Sending directory entry to handset 34
Sensitivity (room monitor) 52
Setting
 date 16
 melody. 62
 time 16
Setting up handset 12
Side keys 2
Signal tone, see Advisory tones

Simplified mode 65
Snooze mode 49
Sound, see Ringtone
Special functions. 64
Specifications. 67
Star key 2
System settings 63

T

Talk key 2, 28
Telephone jack, pin connections. 68
Time Control. 62
Time Control (Night mode). 59
Tone dialling. 64

V

Viewing
 message 45
 network mailbox. 45
Volume
 earpiece. 58
 handset speaker volume. 58
 loudspeaker 58
 ringtone 59, 62

W

Warning tone, see Advisory tones
Writing and editing text 68

Issued by

Gigaset Communications GmbH
Frankenstr. 2a, D-46395 Bocholt

© Gigaset Communications GmbH 2012

All rights reserved. Subject to availability.

Rights of modification reserved.

www.gigaset.com